

Using Avaya J169/J179 IP Phone SIP

© 2020, Avaya Inc. All Rights Reserved.

Note

Using a cell, mobile, or GSM phone, or a two-way radio in close proximity to an Avaya IP telephone might cause interference.

Documentation disclaimer

"Documentation" means information published in varying mediums which may include product information, operating instructions and performance specifications that are generally made available to users of products. Documentation does not include marketing materials. Avaya shall not be responsible for any modifications, additions, or deletions to the original published version of Documentation unless such modifications, additions, or deletions were performed by or on the express behalf of Avaya. End User agrees to indemnify and hold harmless Avaya, Avaya's agents, servants and employees against all claims, lawsuits, demands and judgments arising out of, or in connection with, subsequent modifications, additions or deletions to this documentation, to the extent made by End User.

Link disclaimer

Avaya is not responsible for the contents or reliability of any linked websites referenced within this site or Documentation provided by Avaya. Avaya is not responsible for the accuracy of any information, statement or content provided on these sites and does not necessarily endorse the products, services, or information described or offered within them. Avaya does not guarantee that these links will work all the time and has no control over the availability of the linked pages.

Warranty

Avaya provides a limited warranty on Avaya hardware and software. Refer to your sales agreement to establish the terms of the limited warranty. In addition, Avaya's standard warranty language, as well as information regarding support for this product while under warranty is available to Avaya customers and other parties through the Avaya Support website: https://support.avaya.com/helpcenter/getGenericDetails?detailld=C20091120112456651010 under the link "Warranty & Product Lifecycle" or such successor site as designated by Avaya. Please note that if You acquired the product(s) from an authorized Avaya Channel Partner outside of the United States and Canada, the warranty is provided to You by said Avaya Channel Partner and not by Avaya.

"Hosted Service" means an Avaya hosted service subscription that You acquire from either Avaya or an authorized Avaya Channel Partner (as applicable) and which is described further in Hosted SAS or other service description documentation regarding the applicable hosted service. If You purchase a Hosted Service subscription, the foregoing limited warranty may not apply but You may be entitled to support services in connection with the Hosted Service as described further in your service description documents for the applicable Hosted Service. Contact Avaya or Avaya Channel Partner (as applicable) for more information.

Hosted Service

THE FOLLOWING APPLIES ONLY IF YOU PURCHASE AN AVAYA HOSTED SERVICE SUBSCRIPTION FROM AVAYA OR AN AVAYA CHANNEL PARTNER (AS APPLICABLE), THE TERMS OF USE FOR HOSTED SERVICES ARE AVAILABLE ON THE AVAYA WEBSITE, <u>HTTPS://SUPPORT.AVAYA.COM/LICENSEINFO</u> UNDER THE LINK "Avaya Terms of Use for Hosted Services" OR SUCH SUCCESSOR SITE AS DESIGNATED BY AVAYA, AND ARE APPLICABLE TO ANYONE WHO ACCESSES OR USES THE HOSTED SERVICE. BY ACCESSING OR USING THE HOSTED SERVICE, OR AUTHORIZING OTHERS TO DO SO, YOU, ON BEHALF OF YOURSELF AND THE ENTITY FOR WHOM YOU ARE DOING SO (HEREINAFTER REFERRED TO INTERCHANGEABLY AS "YOU" AND "END USER"), AGREE TO THE TERMS OF USE. IF YOU ARE ACCEPTING THE TERMS OF USE ON BEHALF A COMPANY OR OTHER LEGAL ENTITY, YOU REPRESENT THAT YOU HAVE THE AUTHORITY TO BIND SUCH ENTITY TO THESE TERMS OF USE. IF YOU DO NOT HAVE SUCH AUTHORITY, OR IF YOU DO NOT WISH TO ACCEPT THESE TERMS OF USE, YOU MUST NOT ACCESS OR USE THE HOSTED SERVICE OR AUTHORIZE ANYONE TO ACCESS OR USE THE HOSTED SERVICE.

Licenses

THE SOFTWARE LICENSE TERMS AVAILABLE ON THE AVAYA WEBSITE, HTTPS://SUPPORT.AVAYA.COM/LICENSEINFO. UNDER THE LINK "AVAYA SOFTWARE LICENSE TERMS (Avaya Products)" OR SUCH SUCCESSOR SITE AS DESIGNATED BY AVAYA, ÁRE APPLICABLE TO ANYONE WHO DOWNLOADS, USES AND/OR INSTALLS AVAYA SOFTWARE, PURCHASED FROM AVAYA INC., ANY AVAYA AFFILIATE, OR AN AVAYA CHANNEL PARTNER (AS APPLICABLE) UNDER A COMMERCIAL AGREEMENT WITH AVAYA OR AN AVAYA CHANNEL PARTNER. UNLESS OTHERWISE AGREED TO BY AVAYA IN WRITING AVAYA DOES NOT EXTEND THIS LICENSE IF THE SOFTWARE WAS OBTAINED FROM ANYONE OTHER THAN AVAYA, AN AVAYA AFFILIATE OR AN AVAYA CHANNEL PARTNER; AVAYA RESERVES THE RIGHT TO TAKE LEGAL ACTION AGAINST YOU AND ANYONE ELSE USING OR SELLING THE SOFTWARE WITHOUT A LICENSE. BY INSTALLING, DOWNLOADING OR USING THE SOFTWARE, OR AUTHORIZING OTHERS TO DO SO, YOU, ON BEHALF OF YOURSELF AND THE ENTITY FOR WHOM YOU ARE INSTALLING, DOWNLOADING OR USING THE SOFTWARE (HEREINAFTER REFERRED TO INTERCHANGEABLY AS "YOU" AND "END USER"), AGREE TO THESE TERMS AND CONDITIONS AND CREATE A BINDING CONTRACT BETWEEN YOU AND AVAYA INC. OR THE APPLICABLE AVAYA AFFILIATE ("AVAYA").

Avaya grants You a license within the scope of the license types described below, with the exception of Heritage Nortel Software, for which the scope of the license is detailed below. Where the order documentation does not expressly identify a license type, the applicable license will be a Designated System License as set forth below in the Designated System(s) License (DS) section as applicable. The applicable number of licenses and units of capacity for which the license is granted will be one (1), unless a different number of licenses or units of capacity is specified in the documentation or other materials available to You. "Software" means computer programs in object code, provided by Avaya or an Avaya Channel Partner, whether as stand-alone products, pre-installed on hardware products, and any upgrades, updates, patches, bug fixes, or modified versions thereto. "Designated Processor" means a single stand-alone computing device. "Server" means a set of Designated Processors that hosts (physically or virtually) a software application to be accessed by multiple users. "Instance" means a single copy of the Software executing at a particular time: (i) on one physical machine; or (ii) on one deployed software virtual machine ("VM") or similar deployment.

License types

Designated System(s) License (DS). End User may install and use each copy or an Instance of the Software only: 1) on a number of Designated Processors up to the number indicated in the order; or 2) up to the number of Instances of the Software as indicated in the order, Documentation, or as authorized by Avaya in writing. Avaya may require the Designated Processor(s) to be identified in the order by type, serial number, feature key, Instance, location or other specific designation, or to be provided by End User to Avaya through electronic means established by Avaya specifically for this purpose.

Shrinkwrap License (SR). End User may install and use the Software in accordance with the terms and conditions of the applicable license agreements, such as "shrinkwrap" or "clickthrough" license accompanying or applicable to the Software ("Shrinkwrap License") as indicated in the order, Documentation, or as authorized by Avaya in writing.

Heritage Nortel Software

"Heritage Nortel Software" means the software that was acquired by Avaya as part of its purchase of the Nortel Enterprise Solutions Business in December 2009. The Heritage Nortel Software is the software contained within the list of Heritage Nortel Products located at https://support.avaya.com/LicenseInfo under the link "Heritage Nortel Products" or such successor site as designated by Avaya. For Heritage Nortel Software, Avaya grants Customer a license to use Heritage Nortel Software provided hereunder solely to the extent of the authorized activation or authorized usage level, solely for the purpose specified in the Documentation, and solely as embedded in, for execution on, or for communication with Avaya equipment. Charges for Heritage Nortel Software may be based on extent of activation or use authorized as specified in an order or invoice.

Copyright

Except where expressly stated otherwise, no use should be made of materials on this site, the Documentation, Software, Hosted Service, or hardware provided by Avaya. All content on this site, the documentation, Hosted Service, and the product provided by Avaya including the selection, arrangement and design of the content is owned either by Avaya or its licensors and is protected by copyright and other intellectual property laws including the sui generis rights relating to the protection of databases. You may not modify, copy, reproduce, republish, upload, post, transmit or distribute in any way any content, in whole or in part, including any code and software unless expressly authorized by Avaya. Unauthorized reproduction, transmission, dissemination, storage, and or use without the express written consent of Avaya can be a criminal, as well as a civil offense under the applicable law.

Virtualization

The following applies if the product is deployed on a virtual machine. Each product has its own ordering code and license types. Unless otherwise stated, each Instance of a product must be separately licensed and ordered. For example, if the end user customer or Avaya Channel Partner would like to install two Instances of the same type of products, then two products of that type must be ordered.

Third Party Components

"Third Party Components" mean certain software programs or portions thereof included in the Software or Hosted Service may contain software (including open source software) distributed under third party agreements ("Third Party Components"), which contain terms regarding the rights to use certain portions of the Software ("Third Party Terms"). As required, information regarding distributed Linux OS source code (for those products that have distributed Linux OS source code) and identifying the copyright holders of the Third Party Components and the Third Party Terms that apply is available in the products, Documentation or on Avaya's website at: https:// support.avaya.com/Copyright or such successor site as designated by Avaya. The open source software license terms provided as Third Party Terms are consistent with the license rights granted in these Software License Terms, and may contain additional rights benefiting You, such as modification and distribution of the open source software. The Third Party Terms shall take precedence over these Software License Terms, solely with respect to the applicable Third Party Components to the extent that these Software License Terms impose greater restrictions on You than the applicable Third Party

The following applies only if the H.264 (AVC) codec is distributed with the product. THIS PRODUCT IS LICENSED UNDER THE AVC PATENT PORTFOLIO LICENSE FOR THE PERSONAL USE OF A CONSUMER OR OTHER USES IN WHICH IT DOES NOT RECEIVE REMUNERATION TO (i) ENCODE VIDEO IN COMPLIANCE WITH THE AVC STANDARD ("AVC VIDEO") AND/OR (ii) DECODE AVC VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE AVC VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION MAY BE OBTAINED FROM MPEG LA, L.L.C. SEE HTTP://WWW.MPEGLA.COM.

Service Provider

THE FOLLOWING APPLIES TO AVAYA CHANNEL PARTNER'S HOSTING OF AVAYA PRODUCTS OR SERVICES. THE PRODUCT OR HOSTED SERVICE MAY USE THIRD PARTY COMPONENTS SUBJECT TO THIRD PARTY TERMS AND REQUIRE A SERVICE PROVIDER TO BE INDEPENDENTLY LICENSED DIRECTLY FROM THE THIRD PARTY SUPPLIER. AN AVAYA CHANNEL PARTNER'S HOSTING OF AVAYA PRODUCTS MUST BE AUTHORIZED IN WRITING BY AVAYA AND IF THOSE HOSTED PRODUCTS USE OR EMBED CERTAIN THIRD PARTY SOFTWARE, INCLUDING BUT NOT LIMITED TO MICROSOFT SOFTWARE OR CODECS, THE AVAYA CHANNEL PARTNER IS REQUIRED TO INDEPENDENTLY OBTAIN ANY APPLICABLE LICENSE AGREEMENTS, AT THE AVAYA CHANNEL PARTNER'S EXPENSE, DIRECTLY FROM THE APPLICABLE THIRD PARTY SUPPLIER.

WITH RESPECT TO CODECS, IF THE AVAYA CHANNEL PARTNER IS HOSTING ANY PRODUCTS THAT USE OR EMBED THE H.264 CODEC OR H.265 CODEC, THE AVAYA CHANNEL

PARTNER ACKNOWLEDGES AND AGREES THE AVAYA CHANNEL PARTNER IS RESPONSIBLE FOR ANY AND ALL RELATED FEES AND/OR ROYALTIES. THE H.264 (AVC) CODEC IS LICENSED UNDER THE AVC PATENT PORTFOLIO LICENSE FOR THE PERSONAL USE OF A CONSUMER OR OTHER USES IN WHICH IT DOES NOT RECEIVE REMUNERATION TO: (I) ENCODE VIDEO IN COMPLIANCE WITH THE AVC STANDARD ("AVC VIDEO") AND/OR (II) DECODE AVC VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE AVC VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION FOR H.264 (AVC) AND H.265 (HEVC) CODECS MAY BE OBTAINED FROM MPEG LA, L.L.C. SEE http://www.mpegla.com.

Compliance with Laws

You acknowledge and agree that it is Your responsibility for complying with any applicable laws and regulations, including, but not limited to laws and regulations related to call recording, data privacy, intellectual property, trade secret, fraud, and music performance rights, in the country or territory where the Avaya product is used.

Preventing Toll Fraud

"Toll Fraud" is the unauthorized use of your telecommunications system by an unauthorized party (for example, a person who is not a corporate employee, agent, subcontractor, or is not working on your company's behalf). Be aware that there can be a risk of Toll Fraud associated with your system and that, if Toll Fraud occurs, it can result in substantial additional charges for your telecommunications services.

Avaya Toll Fraud intervention

If You suspect that You are being victimized by Toll Fraud and You need technical assistance or support, call Technical Service Center Toll Fraud Intervention Hotline at +1-800-643-2353 for the United States and Canada. For additional support telephone numbers, see the Avaya Support website: https://support.avaya.com or such successor site as designated by Avaya.

Security Vulnerabilities

Information about Avaya's security support policies can be found in the Security Policies and Support section of https://support.avaya.com/security.

Suspected Avaya product security vulnerabilities are handled per the Avaya Product Security Support Flow (https://support.avaya.com/css/P8/documents/100161515).

Downloading Documentation

For the most current versions of Documentation, see the Avaya Support website: https://support.avaya.com, or such successor site as designated by Avaya.

Contact Avaya Support

See the Avaya Support website: https://support.avaya.com for product or Hosted Service notices and articles, or to report a problem with your Avaya product or Hosted Service. For a list of support telephone numbers and contact addresses, go to the Avaya Support website: https://support.avaya.com (or such successor site as designated by Avaya), scroll to the bottom of the page, and select Contact Avaya Support.

Regulatory Statements

Australia Statements

Handset Magnets Statement:



Danger:

The handset receiver contains magnetic devices that can attract small metallic objects. Care should be taken to avoid personal injury.

Industry Canada (IC) Statements

RSS Standards Statement

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- 1. This device may not cause interference, and
- This device must accept any interference, including interference that may cause undesired operation of the device

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- 1. L'appareil ne doit pas produire de brouillage, et
- L'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Radio Transmitter Statement

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (EIRP) is not more than that necessary for successful communication.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Radiation Exposure Statement

This equipment complies with FCC & IC RSS102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body. This transmitter must not be colocated or operating in conjunction with any other antenna or transmitter.

Cet équipement est conforme aux limites d'exposition aux rayonnements ISEDétablies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 20 cm de distance entre la source de rayonnement et votre corps.

This product meets the applicable Innovation, Science and Economic Development Canada technical specifications.

Japan Statements

Class B Statement

This is a Class B product based on the standard of the VCCI Council. If this is used near a radio or television receiver in a domestic environment, it may cause radio interference. Install and use the equipment according to the instruction manual.

この装置は、クラスB情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。

取扱説明書に従って正しい取り扱いをして下さい。 VCCI-B

Denan Power Cord Statement



Danger:

Please be careful of the following while installing the equipment:

 Please only use the connecting cables, power cord, and AC adapters shipped with the equipment or specified by Avaya to be used with the equipment. If you use any other equipment, it may cause failures, malfunctioning, or fire. Power cords shipped with this equipment must not be used with any other equipment. In case the above guidelines are not followed, it may lead to death or severe injury.



警告

本製品を安全にご使用頂くため、以下のことにご注意ください。

- 接続ケーブル、電源コード、AC アダプタなどの部品は、必ず 製品に同梱されております添付品または指定品をご使用くだ さい。添付品指定品以外の部品をご使用になると故障や動作 不良、火災の原因となることがあります。
- 同梱されております付属の電源コードを他の機器には使用しないでください。上記注意事項を守らないと、死亡や大怪我など人身事故の原因となることがあります。

México Statement

The operation of this equipment is subject to the following two conditions:

- 1. It is possible that this equipment or device may not cause harmful interference, and
- This equipment or device must accept any interference, including interference that may cause undesired operation.

La operación de este equipo está sujeta a las siguientes dos condiciones:

- Es posible que este equipo o dispositivo no cause interferencia perjudicial y
- Este equipo o dispositivo debe aceptar cualquier interferencia, incluyendo la que pueda causar su operación no deseada

Brazil Statement

Este equipamento não tem direito à proteção contra interferência prejudicial e não pode causar interferência em sistemas devidamente autorizados

Power over Ethernet (PoE) Statement

This equipment must be connected to PoE networks without routing to the outside plant.

U.S. Federal Communications Commission (FCC) Statements

Compliance Statement

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

To comply with the FCC RF exposure compliance requirements, this device and its antenna must not be co-located or operating to conjunction with any other antenna or transmitter.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- This device must accept any interference received, including interferences that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designated to provide reasonable protection against harmful interferences in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interferences to radio or television reception, which can be determined by turning the

equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- · Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment . This equipment should be installed and operated with minimum distance of 8 in or 20 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

ENERGY STAR® compliance statement



As an ENERGY STAR partner, Avaya Inc. has determined that this product meets the ENERGY STAR guidelines for energy efficiency. Information on the ENERGY STAR program can be found at www.energystar.gov. ENERGY STAR and the ENERGY STAR mark are registered trademarks owned by the U.S. Environmental Protection Agency.

EU Countries

This device when installed complies with the essential requirements and other relevant provisions of the EMC Directive 2014/30/EU, Safety LV Directive 2014/35/EU, and Radio Equipment Directive 2014/53/EU. A copy of the Declaration may be obtained from https://support.avaya.com or Avaya Inc., 2605 Meridian Parkway Suite 200. Durham, NC 27713 USA.

WiFi transmitter

- Frequencies for 2412-2472 MHz, transmit power: < 20 dBm
- Frequencies for 5180-5240 MHz, transmit power: < 20 dBm

BT transmitter

• Frequencies for 2402-2480 MHz, transmit power: < 6.0 dBm

General Safety Warning

- Use only the Avaya approved Limited Power Source power supplies specified for this product.
- Ensure that you:
 - Do not operate the device near water.
 - Do not use the device during a lightning storm.
 - Do not report a gas leak while in the vicinity of the leak.
 - For Accessory Power Supply in Avaya J100 Series IP Phones— Use Only Limited Power Supply Phihong Technology Co. Ltd. Model: PSAC12R-050, Output: 5VDC, 2.4A.

Trademarks

The trademarks, logos and service marks ("Marks") displayed in this site, the Documentation, Hosted Service(s), and product(s) provided by Avaya are the registered or unregistered Marks of Avaya, its affiliates, its licensors, its suppliers, or other third parties. Users are not permitted to use such Marks without prior written consent from Avaya or such third party which may own the Mark. Nothing contained in this site, the Documentation, Hosted Service(s) and product(s) should be construed as granting, by implication, estoppel, or otherwise, any license or right in and to the Marks without the express written permission of Avaya or the applicable third party.

Avaya is a registered trademark of Avaya Inc.

All non-Avaya trademarks are the property of their respective owners. Linux[®] is the registered trademark of Linus Torvalds in the U.S. and other countries

The Bluetooth™ word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Avaya Inc. is under license.

Device Usage Consent

By using the Avaya device you agree that Avaya, from time to time, may collect network and device data from your device and may use such data in order to validate your eligibility to use the device.

Contents

Chapter 1: Introduction	12
Purpose	12
Chapter 2: Phone overview	13
Physical layout of a J169/179 IP Phone	
Connection jacks for J169/179 IP Phone	
Optional components	
Chapter 3: Getting started	20
Entering the provisioning details	
Identifying the device type during phone boot-up	
Logging in to your phone	
Logging out of your phone	22
Locking your phone	
Unlocking your phone	23
Connecting to a Wi-Fi network	23
Chapter 4: Navigation	24
Cursor navigation	
Navigation cluster	
Text input	25
Line keys	26
Main menu	
General phone icons	27
Presence icons	29
Multiple Level Precedence and Preemption icons	30
Bluetooth icons	30
Wi-Fi icons	30
Chapter 5: Handling incoming calls	32
Answering a call	
Answering a call when on another call	32
Handling calls and conferences using Multiple Device Access	33
Ignoring a call	33
Declining a call	34
Chapter 6: Handling outgoing calls	35
Making a call by using the manual dial mode	35
Making a call by using the auto-dial mode	35
Redialing a number	36
Making a call by using speed dial	37
Making a call from the local Contacts list	
Making a call from the corporate database Contacts list	37
Making an international call	38

Emergency call	38
Making an emergency call	39
Chapter 7: Call related features	40
Muting and unmuting a call	40
Placing a call on hold and resuming the call	
Chapter 8: Managing Contacts	
Adding a new contact	
Adding a contact from the Recents list	
Editing a contact	
Doing a quick search for a contact	
Viewing the contact details	
Searching for a contact	
Combining contacts	44
Deleting a contact	45
Creating a local Contacts group	45
Adding a contact to the local group	46
Removing a contact from the local group	46
Assigning a ringtone to a contact	47
LDAP Directory	47
Setting LDAP Directory as the contact search source	
Searching LDAP contacts	48
Chapter 9: Managing Recents	50
Call log	50
Making a call from Recents	50
Viewing the Recents details	51
Deleting a call record from Recents	
Clearing the Recents list	52
Chapter 10: Managing conference calls	53
Adding a person to an active call	53
Adding a person on hold to a conference call	53
Putting a conference call on hold and resuming a call	
Viewing the details of a conference	54
Dropping or Disconnecting the last participant from a conference call	55
Chapter 11: Advanced features	56
Accessing the Features screen	56
Active call shortcut keys	56
Making a call transfer with a shortcut key	57
Making a conference call with a shortcut key	57
Activating the screen saver	58
Activating Send All Calls	
Automatic Callback	
Setting up Automatic Callback	59
Autodialing a pre-assigned number	59

Contents

Blocking your extension from displaying during calls	60
Bridged Call Appearance	
Making a call on a bridged line	60
Answering a bridged line call	61
Joining a call on a bridged line	61
Busy Indicator	61
Busy Indicator icons and LED indication	62
Busy Indicator call operations	62
Call Transfer to a monitored user	63
Calendar	64
Accessing calendar	64
Configuring the Microsoft [®] Exchange Server calendar	65
Reviewing your Calendar event	
Call forwarding	66
Forwarding a call to another extension	67
Setting enhanced call forwarding	68
Call forwarding to your cell phone using EC500	69
Calling in your intercom group	
Call Parking	70
Parking a call	70
Unparking a call	71
Call Pickup	71
Answering a call for a Call Pickup group member	72
Answering a call in the same Call Pickup group	72
Answering a call using the extension number	73
Call recording	73
Recording a call	73
Call Transfer	74
Making a consultative transfer	74
Making a blind transfer	75
Crisis alert station	75
Acknowledging the crisis alert	76
Emergency caller information	76
Stopping the crisis alert	77
Acknowledging the crisis alert after an error in the first acknowledgment	77
Displaying your extension on outgoing calls	78
Excluding others from bridging on to your call	78
Extending a call to your cell phone	79
Hunt Group Busy	79
Using Hunt Group Busy	
Interrupting a call with a whisper page	80
Limit Incoming Calls	80
Activating Limit Incoming Calls	80

	Deactivating Limit Incoming Calls	. 81
	Long-term acoustic exposure protection	. 81
	Configuring Long term acoustic protection	. 82
	Multiple Device Access	. 83
	Using URI dialing to make a call	. 83
	Making a priority call	. 84
	Multicast Paging	. 84
	Sending a multicast page	. 85
	No Hold Conference	. 85
	Adding a participant to no hold conference	. 86
	Precedence call	. 86
	Making a precedence call by using the Main menu	87
	Making a precedence call by using dial plan configuration	. 87
	Pre-configuration of keys	. 87
	Presence	. 88
	Viewing the Presence status of your contacts	. 88
	Changing your Presence status	. 88
	Retrieving a voice message	. 89
	Service Observe	89
	Activating Service Observe	. 90
	Deactivating Service Observe	
	Assisting an agent on an observed call	
	SLA Mon [™]	
	Shared control	
	Team Button	. 93
	Answering an active call on a monitored extension	
	Viewing the status of monitored stations	
	Speed dialing to a monitored extension	
	Transferring a call to a monitored phone	
	Monitoring other extensions at a glance	
	Tracing a malicious call	
	Using a Guest Login	
	WML browser	
	Accessing the WML browser	. 98
Ch	apter 12: Customization	. 99
	Phone	
	Setting the dialing mode	
	Displaying call timers	
	Setting key repeat delay	
	Setting redial options	
	5 5 1	101
	Setting Mute alert	
	Visual alerting	102

Contents

Customizing phone keys	103
Restoring customized keys to default	
Applications	
Enabling the Away timer	
Enabling phone auto-lock	
Turning call history on and off	106
Microsoft® Exchange account integration	106
Entering Microsoft® Exchange credentials for basic authentic	
Entering Microsoft® Exchange credentials for OAuth authenti	
Enabling and disabling Microsoft® Exchange contact integrat	ion 108
Calendar settings	
Activating Do not disturb	111
Redirecting calls when Do Not Disturb is active	111
Audio	112
Turning automatic gain control on or off	112
Enabling and disabling Bluetooth	112
Pairing a Bluetooth enabled headset with your phone	113
Turning button clicks on and off	113
Turning error tones on and off	114
Enabling wireless headset bidirectional signaling	
Setting headset mic level	
Configuring hearing aid compatibility	
Setting a headset profile	
Setting a personalized ringtone	
Display	
Changing the background image	
Changing the screen saver	
Setting the screen saver details	
Adjusting the brightness of a phone screen	
Setting the display language	
Setting the backlight timer	
Setting the time format	
Setting the date format	
Setting the time zone	
Setting the text size	
Setting the phone screen width	
Setting the network mode	
Setting the network configuration	
Connecting to a Wi-Fi network	
Chapter 13: Troubleshooting	
Limited access during failover	
Recording audio parameters	
Viewing the Product ID	

Viewing the Device type	128
Viewing the Server type	
Chapter 14: Resources	129
Documentation	
Finding documents on the Avaya Support website	131
Avaya Documentation Center navigation	131
Viewing Avaya Mentor videos	132
Support	133

Chapter 1: Introduction

Purpose

This document describes the features of the Avaya J169/J179 IP Phone and also provides instructions on how to use this phone.

This document is for end users.

Chapter 2: Phone overview

Avaya J169/J179 IP Phone is a phone for business communications. The phone supports 96 buttons. The primary display of the phone provides 96 buttons by scrolling or paging using the Navigation Cluster. Optionally, the phone supports up to three button modules, and each button module supports displaying 24 buttons of the 96 buttons. If only one button module is attached to the phone, then the button module supports paging three pages of 24 buttons.

For more information about Avaya J100 Expansion Module, see Using Avaya J100 Expansion Module for SIP in https://support.avaya.com/.

Avaya J169 IP Phone has a grayscale display, and Avaya J179 IP Phone has a color display.

Physical specifications

- 8 buttons with red and green dual LEDs
- 320 x 240 pixel display
- · Dual-position stand, optional wall mount stand
- Gigabit Ethernet (10/100/1000 Mbps) line interface
- Second Gigabit Ethernet (10/100/1000 Mbps) interface
- PoE Class 1, supports 802.3az, optional AC to 5V adapter
- Wideband audio in the handset, headset, and handsfree
- Full duplex speakerphone
- · Ergonomic hearing aid compatible handset supports TTD acoustic coupler
- · Rich, classic, alternate ringtones
- Four soft keys
- Hard buttons for phone:
 - Messages
 - Contacts
 - Recents
 - Navigation cluster
 - Headset
 - Speaker
 - Volume
 - Mute

Phone overview

- Main menu
- Phone key
- LED buttons for phone:
 - Messages
 - Recents
 - Headset
 - Speaker
 - Mute

Related links

Physical layout of a J169/179 IP Phone on page 15


Connection jacks for J169/179 IP Phone on page 17

Optional components on page 19

Understanding Avaya J179 IP Phone (Video)

Configuring the Avaya J100 Expansion Module (Video)

Physical layout of a J169/179 IP Phone



No.	Name	Description
1	Beacon LED	Provides visual alerts for the following:
		Incoming call
		Voice mail
2	Phone display	Displays two areas:
		Top Bar: It is always visible, displays communication status, time, date, and device status.
		2. Application area displays the following:
		 Application header: It displays the context specific application title, and one or more subtitles. Depending on the appearance type and the call state, the header displays details of the call.
		 Application content area: It displays menus, lists, pop-up windows, images, or other application content.
		 Soft key labels area: It displays labels with information about the state of soft key buttons.
3	Line keys	Used to select the corresponding line or feature. Each line key has a combination of red and green LEDs that provide call or feature specific visual alert.
		Note:
		The default action depends on the application and the context.
4	Soft keys	Used to select the corresponding label of context-specific actions.
		With the Help soft key, you can view a short description of the features available on your phone.
5, 7	Navigation cluster	Used to navigate on the Phone screen and other menus.
		• Up and Down arrow keys: To scroll up and down.
		 Right and Left arrow keys: To move cursor in the text input field, and to toggle values in the selection fields.
		OK button: The center button of the navigation cluster. Used to select the action assigned to the first soft key.
11	Voicemail	Used to dial the configured voice mail number to receive a voice message.
12	Headset	Used to turn on headset, and also to toggle an ongoing call from the speaker to the headset.
13	Speaker	Used to turn on the speaker.

No.	Name	Description
14	Volume	Used to adjust volume of a handset, a speaker, or a ringtone.
		• (+): To increase the volume.
		(-): To decrease the volume.
15	Mute button	Used to mute or unmute the outgoing audio.
16	Handset	Used to receive or make calls.

Application keys provide direct access to the corresponding applications.

No.	Application keys	Description
6	Phone key	Displays the Phone screen.
8	Main menu	Displays a list of options, such as Features, Applications, Settings, Network information, Administration, and About.
9	Contacts	Displays the entries in your Contacts list.
10	Recents	Displays the list of all calls.

Related links

Phone overview on page 13


Understanding Avaya J179 IP Phone (Video)

Configuring the Avaya J100 Expansion Module (Video)

Connection jacks for J169/179 IP Phone

The following image illustrates the connection jacks that are present on the back panel of Avaya J169/J179 IP Phone.

The image schematically describes which device to connect to which jack.



No.	Name	Description
1	5V DC Jack	To connect the power supply.
2	Network port	To connect the Ethernet cable.
3	PC port	To connect the computer.
		Note:
		PC port is disabled when a Wi-Fi network is used.
4	Headset Jack	To connect the headset.
5	Handset Jack	To connect the handset.
6	WLAN Module Panel	To integrate the wireless module for Wi-Fi/Bluetooth support.
		★ Note:
		WLAN Module Panel is not provided in the Avaya J169 IP Phone.

Related links

Phone overview on page 13
Understanding Avaya J179 IP Phone (Video)
Configuring the Avaya J100 Expansion Module (Video)

Optional components

You can use the following optional components with the phone:

- PSAC12R-050 5V DC Power adapter
- Avaya J100 Expansion Module
- GSPPoE Avaya 48V PoE power inserter

Related links

Phone overview on page 13

Understanding Avaya J179 IP Phone (Video)

Configuring the Avaya J100 Expansion Module (Video)

Chapter 3: Getting started

Entering the provisioning details

About this task

Enter the provisioning server address if the phone prompts, for example, when you connect to the network for the first time.

Before you begin

Obtain the provisioning server address from the system administrator.

Procedure

- 1. When you boot the phone for the first time, the Auto Provisioning screen displays Do you want to activate Auto Provisioning now?, press one of the following:
 - **Yes**: To connect to the Device Enrollment Services server to obtain the provisioning server address and ignore the provisioning server address from the DHCP.
 - No: To obtain the provisioning server address from the DHCP server.

In case of a time out, and the DHCP does not provide the provisioning server address, the phone selects **Yes**.

If the connection to Device Enrollment Services is successful, and the phone receives the provisioning server address, the phone continues to boot and not prompt you for the provisioning server address.

If the connection to Device Enrollment Services is successful, and the phone does not receive the provisioning server address from Device Enrollment Services, the phone prompts you for an Enrollment code. Contact your administrator for an Enrollment code. When you enter the valid Enrollment code, the phone continues to boot and not prompt you for the provisioning server address.

If you do not have an Enrollment code, press Cancel. The phone continues to boot using the DHCP.

The phone displays the Starting message. If the phone does not receive the provisioning server address from the Device Enrollment Services or the DHCP server, the phone displays the Enter provisioning details screen.

- 2. On Enter provisioning details screen, press one of the following:
 - Config: To enter the provisioning server address.

- **Never**: To never prompt for the provisioning server address.
- Cancel: To cancel the prompt and display the Login screen.
- 3. After you have pressed **Config**, enter the provisioning server address in the **Address** field. The address is an alphanumeric URL like http://myfileserver.com/j100/.

Tip:

To enter the dot symbol (.) in the field, press the alphanumeric soft key to toggle to the ABC mode.

To enter the forward slash symbol (/) in the field, press the / soft key.

4. (Optional) Enter the Group number.

Obtain the Group number from your system administrator. The value ranges from 0 to 999. 0 is the default value. If you do not enter any value in this field, the phone uses the default value.

5. Press Save.

The phone continues to boot and connect to the provisioning server address for provisioning configuration.

Related links

Setting Up the Avaya J179 IP Phone (Video)

Identifying the device type during phone boot-up

About this task

Avaya J100 Series IP Phones screen displays the device type during the phone boot-up. This feature is supported only in the phone software version 4.0.3 and later.

Procedure

- 1. Set up the phone hardware.
- 2. Plug the Ethernet cable to the phone.

The phone powers up and starts to initialize.

The phone primary screen displays one of the following as the backsplash screen:

- A screen with Avaya text for Avaya SIP phones
- A screen with Open SIP text for Open SIP phones

Logging in to your phone

Before you begin

Your extension and password are provided by your administrator.

Procedure

- 1. On the Login screen in the **Username** field, type your extension.
- 2. Press Enter.
- 3. In the **Password** field, type your password.
- 4. Press Enter.

Logging out of your phone

About this task

Use this procedure to log out of your primary or guest user extension.

Note:

After a guest user logs out, the primary user will be logged in.

Procedure

- 1. Press Main menu.
- 2. Scroll to **Applications**, and press **Select**.
- Scroll to Log out, and press Select.
- 4. In the confirmation window, press **Log out**.

Related links

Using a Guest Login on page 97

Locking your phone

About this task

You can lock your phone to prevent unauthorized use of the phone when you are away. Locking your phone does not log you out, you can still receive all calls and make calls to emergency numbers.

To lock the phone, press **Main menu**, and select **Applications > Lock**.

Unlocking your phone

About this task

You can unlock your phone using a PIN or a password. Depending on the configuration made by your administrator, the phone screen displays the field for entering either a PIN or a password. A PIN is a digit-only value whereas a password can be an alphanumeric value.

If you do not know or remember your PIN or password, contact your administrator.

You cannot unlock the phone if you enter an incorrect PIN or password.

Your administrator sets a limit to the number of incorrect attempts. If you exceeded the limit, the phone temporarily blocks you from attempting to unlock the phone for a period that your administrator specifies.

To unlock the phone, press **Unlock** and enter the PIN or password.

Connecting to a Wi-Fi network

About this task

Use this procedure to connect your phone to an available Wi-Fi network.

Before you begin

Make sure your phone is connected to a Wi-Fi module and Wi-Fi connection is enabled by your administrator.

Procedure

- 1. From the Main Menu, navigate to Settings > Network > Network Mode.
- 2. Toggle Wi-Fi.
- 3. Scroll to a Wi-Fi network you want to connect to from the list of available networks and press **Connect**.
- 4. Press **Info** to view the selected network details.

Next steps

Switching back to Ethernet network mode causes the phone to reboot.

Chapter 4: Navigation

Cursor navigation

You can use the navigation cluster for cursor movement or selection of options on the Phone screen or in other menus. The navigation cluster has the following keys on the phone:

- Left Arrow
- Right Arrow
- Up Arrow
- Down Arrow
- OK

Related links

Navigation cluster on page 24

Navigation cluster

The effect of pressing a navigation key depends on the current application and context.

Key name	Description
Left Arrow and Right Arrow	Use these keys in:
	Text input fields to move the cursor position.
	Selection fields to toggle field values and select options in lists and menus.
	Half-width displays to move the selection left or right.
	Scrolling between pages when navigating the phone screen, provided that page scrolling mode is switched on by your administrator.
	The directional keys are context-sensitive.
Up Arrow and Down Arrow	Use these keys to scroll vertically in lists, menus, and popup windows.

Key name	Description
OK , center button of the navigation cluster.	Unless otherwise specified, use this key for the first or left-most soft key action.
	If there are two or more pages of soft keys, the OK key is active only when the phone screen displays the first page of soft keys.

Related links

Cursor navigation on page 24

Text input

You can use the dial pad or the text input soft keys to edit and enter text in the text input fields of the phone.

Input field

Depending on the application and context, a text input field is a text box with a label. The user interface displays labels on the left side of the text box or in the line preceding the text box. An input field can be blank or display a current value that can be modified. The user interface displays input cursors on the right side of the current value or, if the input field is blank, on the left side of the text box.

Hint text

Depending on the application and context, a text box contains hint text. The user interface displays hint text on the left side of the text box in grey, italic font. The interface replaces the hint text with the actual text that you enter. The interface displays the hint text again when you clear the entered text. The interface does not display the hint text if the field contains a value.

Text truncation

When the space in the input area cannot display the full current value, the user interface truncates the text. The interface truncates the text from the left side and displays a blank space with a cursor on the right side of the input field for a new entry. When you enter a new character, the interface truncates the existing character from the left side of the display.

Active language text direction

When the text direction of the active language is right-to-left, the text entry rules are reversed. The user interface:

- Displays the hint text on the right side of the text box.
- Displays the input cursor on the left side of the current character or, if the input field is blank, on the right side.
- Displays the new character on the left side of the current character.
- Deletes the character on the right side of the cursor when you press **Backspace**.

Line keys

The line keys are context-sensitive. When you press a line key:

- In full-width lists, the user interface selects the corresponding line or the object.
- In half-width lists, the interface selects the list item adjacent to the key.
- In page scroll mode and then scroll on to the next or previous page, the selected item remains highlighted.

Input line

The following actions take place when you press the line key against the input lines.

- Selects the corresponding line for the line which accepts user input.
- Displays the cursor after the last character of the existing content if the line is an input line. If an input line is selected, the interface performs no action even if the cursor is in the middle of the line.
- · Performs the action of the first soft key for the line which does not accept user input even if the line is already selected.

For example, when you press a line key in Contacts, the interface initiates a call to the contact because the first soft key represents the Call key.

Main menu

The following table lists the Main menu icons used in Avaya J169/J179 IP Phones:



🔀 Note:

The icons of Avaya J169 IP Phone and Avaya J179 IP Phone look similar but Avaya J169 IP Phone has grayscale icons and Avaya J179 IP Phone has color icons.

Icons	Name	Description
	Features	To access administrator activated features.
	Applications	 To access phone applications such as Contacts, Recents, and Activate screen saver. To sign off the phone, to protect your settings, or to let another user log in.
©	Settings	To change your phone settings, customize button labels, adjust brightness, audio settings, assign speed dial entries, etc.
H	Network information	To check network settings.

Icons	Name	Description
P	Administration	To access administration settings.
①	About	To view the phone model, software version, default device type, and the default server type.

General phone icons

The following table lists the icons used in Avaya J169/J179 IP Phones:



Note:

The icons of Avaya J169/J179 IP Phones look similar but the Avaya J169 IP Phone has grayscaled icons and the Avaya J179 IP Phone has colored icons.

Icon	Description
₹.	Microphone is muted.
C	Missed call on your phone. You can see this icon in the Recents application.
U	Incoming call; indicates you have answered this call. You can see this icon in the Recents application.
€	Outgoing call; indicates you have made this call. You can see this icon in the Recents application.
<u>U</u>	Bridged call; indicates this line is being used for a call on another phone.
	Incoming call is alerting.
4	Outgoing call; indicates you have made this call.
•	Call is active.
	Call is on hold.
	Call is on hold during a conference or transfer call setup.
	Conference is active.
=	Conference is on hold.
$\triangleleft \triangleright$	Use the Right or Left navigation arrow to see more pages / screens / options.

Icon	Description
() °	Scroll left for other options.
• ▷	Scroll right for other options.
O	Team icon indicating this team member is available.
0	Team icon indicating this team member is busy on a call and unavailable.
8	Team icon indicating this team member is not on a call, but is forwarding incoming calls.
6	Team icon indicating this team member is busy on a call and is forwarding incoming calls.
A	Indicates that the phone is not connected to the SIP proxy server and is operating in Failover mode. Some features might not be available or work incorrectly.
	If the appearance line displays this icon, it indicates that the phone has encountered a failure and has preserved the media session until the user hangs up.
	This icon can also indicate that the phone is connected to the call server but the features are not available.
	The EC500 feature is on.
	The Do not disturb feature is on.
(+	The Call forward feature is on.
RED	Indicates that the call is using a wideband codec for excellent voice quality.
	Indicates a low network performance or presence of local network issues that might result in lower call quality.
()	The Limit Number of Concurrent Calls (LNCC) feature is on.
CTRL	Indicates that the SLA Mon [™] agent has taken control of the phone.
REC	Indicates that the call is being recorded for SLA Mon [™] .
•	Indicates that the audio of this call is secure.
©	Indicates that the audio alert for incoming calls is off.
*	Indicates the Bluetooth feature is on.

Icon	Description
9	Indicates that you have missed a call. The number in the icon indicates the number of missed calls.
①	Indicates that you have missed a call. The + in the icon indicates that the number of missed calls are more than 9.
(# [*]	Autodialing feature

Presence icons

Presence icons for Avaya J169 IP Phone and Avaya J179 IP Phone look similar, but Avaya J169 IP Phone has grayscale icons and Avaya J179 IP Phone has color icons.

Icon	Status	Description
	Available	Contact is available and can communicate.
3	On a call	Contact is on a call.
0	Busy	Contact is busy.
0	Away	Contact is away from the phone.
0	Do Not Disturb	Contact does not want to communicate.
0	Out of Office / Offline	Out of Office: Contact is out of office.
		Offline: Contact is offline or wants to appear invisible.
0	Unknown	The presence status of the contact is unknown or the phone is not registered.

Related links

<u>Changing your Presence status</u> on page 88 <u>Changing your Presence status</u> on page 88

Multiple Level Precedence and Preemption icons

The following table lists the icons used in Avaya J169/J179 IP Phone. Note that the icons of Avaya J169 IP Phone and Avaya J179 IP Phone look similar but Avaya J169 IP Phone has grayscale icons and Avaya J179 IP Phone has color icons.

Icon	Precedence level	Description
	Priority	Priority icon for a priority call.
	Routine	Routine icon for a regular call.
	Immediate	Immediate icon for a priority call with a higher precedence value than Priority.
	Flash	Flash icon for a priority call with a higher precedence value than Immediate.
	Flash Override	Flash override icon for a priority call with the highest precedence.

Bluetooth icons

The following table lists the Bluetooth icons used in the Avaya J179 IP Phone:



Avaya J169 IP Phone does not support the Bluetooth feature.

Icon	Description
2	Bluetooth headset is connecting.
*	Bluetooth headset is connected.
G	Default Bluetooth headset.
2	Unpaired Bluetooth headset.

Wi-Fi icons

The following table lists the Wi-Fi icons used in the Avaya J179 IP Phone:

Note:

Avaya J169 IP Phone does not support the Wi-Fi feature.

Icon	Description
○	Non-secure Wi-Fi network is detected.
*	Secure Wi-Fi network is detected.
6	Wi-Fi network is out of range or offline.

Chapter 5: Handling incoming calls

Answering a call

About this task

Use this procedure to answer a call. When you receive a call, the phone does the following:

- · Generates audio-visual alerts.
- Displays the caller's name or number.

Note:

When the Incoming call pop-up window is displayed, the only visual alert is the flashing beacon LED. If you press **Ignore**, both the beacon LED and line key LED start flashing.

Procedure

Do one of the following:

- · Lift the handset.
- · Press Speaker.
- Press OK Button.
- Press the Answer soft key.
- · Press Headset.

You cannot answer BLF and SCACall Park calls using the Bluetooth headset. The headset does not play an alert tone for these calls.

Related links

Using Contacts (Video)

Answering a call when on another call

About this task

You can receive a call on a secondary call appearance only if the call appearance is free.

Procedure

Press one of the following:

- The **Answer** soft key
- OK Button

The phone puts the first call on hold and moves to the second call.

Handling calls and conferences using Multiple Device Access

About this task

With the Avaya Aura® and Multiple Device Access feature, you can have up to ten devices configured with the same extension number. You can use this extension number to transfer active calls between your devices.

Before you begin

Ensure that the system administrator has activated the Multiple Device Access feature (MDA) for your extension.

Procedure

- 1. Initiate a call from your phone.
- 2. To transfer the call to another phone, press **Bridge** on your phone.

If the MDA phone that is joining the call uses a different signaling mode address family, you might notice the Limited Service icon appear on your device for a brief moment. After the MDA phone that is joining the call switches to using the signaling mode address family of the active call, the icon disappears.

Related links

Adding a participant to no hold conference on page 86 Multiple Device Access on page 83

Ignoring a call

About this task

When you do not want to answer a call or you are on another call, you can ignore the new incoming call. When you ignore a call, only the ring alert on your phone stops, you can still answer this call within its ring time by using the Navigation cluster to select the call and answer it.

Procedure

On the Incoming call screen, press one of the following:

- Ignore soft key
- + volume button
- · volume button

The phone turns off the audio alert.



Note:

If you ignore a call using the Bluetooth headset, to answer the ignored call, press Answer or **Headset** button on the phone.

Declining a call

About this task

You can decline an incoming call when you do not want to answer a call. The incoming call is declined depending on the Call decline policy set by your administrator. Contact your administrator to enable this feature for your extension and also to know about the Call decline policy.

Before you begin

Ensure that the feature is activated by the administrator. Contact your administrator for details.

Procedure

On the incoming call screen, press **Decline** soft key.

Result

The call is declined. Depending on your Call decline policy, the caller receives one of the following alert:

- · An audio message alert
- A busy tone alert

Chapter 6: Handling outgoing calls

Making a call by using the manual dial mode

About this task

In a manual dial mode, you can edit the dialed input and initiate a call using the current dialed string. When you initiate a call, there is no dial tone, and no time out for completing the dialed string.

- Do one of the following:
 - Lift the handset.
 - Press Speaker.
 - Press Headset.
- Dial the number, and press the **Call** soft key or **OK** button.

Or

• Just dial the number, and press the Call soft key or OK button.

If your system administrator has enabled the digit mapping feature the phone can automatically correct wrongly dialed numbers or prevent you from dialing certain numbers.

Related links

Setting the dialing mode on page 99

Making a call by using the manual dial mode

Setting the dialing mode on page 99

Making a call by using the auto-dial mode on page 35

Making a call from the corporate database Contacts list on page 37

Searching for a contact on page 44

Basic call handling (Video)

Basic call handling (Video)

Making a call by using the auto-dial mode

About this task

In an auto-dial mode, when you initiate a call by off-hook, you hear a dial tone until you press any digit from the dial pad. You can edit a partially entered dialed input after initiating a call. You hear a

DTMF feedback tone for the digits pressed on the dial pad. The phone automatically places the call when it detects that the dialing string is complete or when there is a time out.

To initiate a call quickly, you can press the # key to indicate the end of the dial, and the phone places the call.

Procedure

- 1. Do one of the following:
 - Lift the handset.
 - · Press Speaker.
 - · Press Headset.
- 2. Dial the number.

Or

3. Just dial the number.

Related links

Setting the dialing mode on page 99

Redialing a number

About this task

You can redial the most recently dialed number.

Before you begin

Ensure that the call history is not empty.

Procedure

1. Press **Redial** soft key.

The phone dials the most recently dialed number.

- 2. (Optional) To see the list of dialed numbers:
 - a. Scroll to the number you want to redial.
 - b. Press Call.

Related links

Setting redial options on page 100

Making a call by using speed dial

Before you begin

Ensure you have speed dial numbers assigned to your contacts.

Procedure

Press and hold the dial pad key assigned to the number you want to call.

Related links

Assigning speed dial entries on page 101

Making a call from the local Contacts list

Procedure

- 1. Press Contacts.
- 2. Scroll to the contact you want to call.
- 3. **(Optional)** Press the digits on the dial pad that correspond to the letters of the name of the person you want to call.

For example, press 76484 to search for someone whose name is Smith.

4. Press Call.

Related links

Making a call from the local Contacts list

Setting the dialing mode on page 99

Making a call by using the auto-dial mode on page 35

Making a call from the corporate database Contacts list on page 37

Searching for a contact on page 44

Making a call from the corporate database Contacts list

About this task

Depending on the configuration by your administrator you may be able to search and call contacts from other remote contacts lists or directories.

- 1. Press Contacts.
- 2. Press Search.
- 3. Enter the digits on the dial pad that correspond to the name of the person you want to call.

For example, press 76484 to search for someone whose name is Smith.

4. Press Search again.

The phone displays the contact saved in the corporate database.

5. Press Call.

Related links

Searching for a contact on page 44

Making an international call

Procedure

- 1. Press and hold the **0** key to enter the plus sign (+).
- 2. Dial the number that you want to call.

Emergency call

Emergency calling is used to connect to a preset emergency services number. The emergency service number is configured by the administrator.

You can make an emergency call from the following screens:

- Login screen
- · Phone screen
- Lock screen

In the IP Office environment, you can make an emergency call only when you are logged in to your phone.

If your system administrator configures emergency calling for your phone, the Phone screen displays the **Emerg** soft key.

Using the **Emerg** soft key, you can dial only the number that is given the highest priority by the system administrator. Alternatively, you can dial the emergency numbers by using the dial pad in the following cases:

- The **Emerg** soft key is unavailable.
- The **Emerg** soft key is available, but you want to dial an emergency number that is not set by the system administrator.

In the IP Office environment, the **Emerg** soft key is unavailable. You must dial the emergency number by using the dial pad.

Making an emergency call

Before you begin

Ensure that the **Emerg** soft key is assigned by your administrator.

Procedure

Do one of the following:

- On the Phone screen, press the **Emerg** soft key, and again press **Emerg** when the phone prompts you for confirmation.
- Dial the emergency number by using the dial pad.

Chapter 7: Call related features

Muting and unmuting a call

About this task

If you mute a call on the phone, you must unmute it using the **Mute** button. If you mute the call on the Bluetooth headset, you must unmute it on the headset.

Procedure

1. To mute an active call, press Mute.

The Mute button is lit.

2. To unmute the call, press Mute again.

Related links

Basic call handling (Video)

Placing a call on hold and resuming the call

About this task

During a call, you can place the call on hold. When you put a call on hold, both you and the caller cannot hear each other on the call. While a call is on hold, you can call other contacts. When multiple calls are held, you can return to the held call by using the up and down arrow keys to scroll to the required call.

- 1. To put an active call on hold, press the **Hold** soft key, or press the line key of the active call.
- 2. To resume the held call, press the **Resume** soft key, or press the line key of the held call.

Chapter 8: Managing Contacts

Adding a new contact

About this task

Use this procedure to add a contact to the phone. You can save up to 250 contacts.

Procedure

- 1. Press Contacts.
- 2. **(Optional)** To navigate through **Main menu**, do the following:
 - a. Scroll to **Applications**, and press **Select**.
 - b. Scroll to Contacts, and press Select.
- 3. Do one of the following:
 - If your Contacts list is empty, press New.
 - If your Contacts list is not empty, press **More** > **New**.
- 4. Use the dial pad to enter the contact's first and last name in the corresponding fields.
 - Press the number key that corresponds to the letter or number that you want to enter.
 - If the characters are on the same key, pause before entering the next character.
 - To enter a space, press 0.
 - Enter the remaining letters or numbers.
 - To enter a symbol, press **More** > **Symbol**. Use the navigation arrows to highlight the symbol that you want to enter and press **Insert**.
 - To delete the last character, press the **Backspace** soft key.
- 5. Enter the extension.

The contact extension can include uppercase and lowercase letters, numbers 0 - 9, and special symbols, such as comma (,), plus (+), and dot (.).

6. Press Save.

Related links

Adding a contact to the local group on page 46 Using Contacts (Video)

Adding a contact from the Recents list

About this task

Use this procedure to add a number to your Contacts list from your call history.

Procedure

- 1. Press Recents.
- 2. Scroll to the required number, and press **+Contact**.
- 3. In the **First name** and **Last name** fields, type the relevant information.

The phone assigns the extension number to **Last name**. You can remove the extension number from this field and add other information.

4. Press Save.

Editing a contact

Procedure

- 1. Press Contacts.
- 2. **(Optional)** To navigate through **Main menu**, do the following:
 - a. Scroll to **Applications**, and press **Select**.
 - b. Scroll to Contacts, and press Select.
- 3. Select the contact.
- 4. Press Details > Edit.
- 5. Scroll to the field to edit.
- 6. Use the dial pad and soft keys to change the contact information.
- 7. Press Save.

Doing a quick search for a contact

About this task

Using the Quick Search feature of the phone, you can quickly search for a saved contact from the Contacts list without entering the entire name of the contact.

Before you begin

Ensure that at least one contact is available in the Contacts list.

Procedure

- 1. Press Contacts.
- 2. **(Optional)** To navigate through **Main menu**, do the following:
 - a. Scroll to Applications, and press Select.
 - b. Scroll to Contacts, and press Select.
- 3. Press the key corresponding to the first letter of the first or last name of the contact on the dial pad.

Result

The phone displays all the contacts whose first or last name begins with the letter associated with the pressed key.

Viewing the contact details

About this task

Use this procedure to view the details of a contact. You can call, edit, or delete a contact from the Details window.

Before you begin

You must have at least one contact in the Contacts list.

- 1. Press Contacts.
- 2. **(Optional)** To navigate through **Main menu**, do the following:
 - a. Scroll to Applications, and press Select.
 - b. Scroll to Contacts, and press Select.
- 3. Select the contact that you want to view.
- 4. Press Details.
 - To call the contact, press Call.
 - To edit the contact, press Edit.
 - To delete the contact, press **Delete**.
 - To view more options, press **More**.

Searching for a contact

About this task

Use this procedure to search contacts from the following:

- My contacts: J100 local contact entries
- · My Exchange: exchange integration, My contacts
- · Global Exchange: exchange integration, global contacts
- System contacts: Avaya Aura contacts
- LDAP: LDAP directory

Procedure

- 1. Press Contacts.
- 2. (Optional) To navigate through Main menu, do the following:
 - a. Scroll to Applications, and press Select.
 - b. Scroll to Contacts, and press Select.
- 3. Press Search > More > Sources.
- 4. In **Contact sources**, press **Toggle** for the required directory.
- 5. Press Save.
- 6. Use the dial pad to enter the name, and press **Search**.
- 7. (Optional) To add the contact to the local Contacts list, press +Contact.

Related links

Making a call from the corporate database Contacts list on page 37 Using Contacts (Video)

Combining contacts

About this task

Use this procedure to merge the phone number of the current contact with the existing local contact.

Before you begin

Ensure the Contacts list is not empty.

Procedure

1. Press Contacts.

- 2. **(Optional)** To navigate through **Main menu**, do the following:
 - a. Scroll to **Applications**, and press **Select**.
 - b. Scroll to Contacts, and press Select.
- 3. Scroll to the contact that you want to combine, and press **Details > More > Combine**.

The select mode displays the Contacts list without the current content.

4. To combine the current contact, scroll to the existing contact, and press **Select**.

The current contact will be deleted from the Contacts list and merged with the local contact.

Deleting a contact

Procedure

- 1. Press Contacts.
- 2. **(Optional)** To navigate through **Main menu**, do the following:
 - a. Scroll to Applications, and press Select.
 - b. Scroll to Contacts, and press Select.
- 3. Select the contact to delete.
- 4. Press **Details** > **More** > **Delete**.
- 5. Press one of the following:
 - **Delete**: To delete the contact.
 - · Cancel: To cancel the action.

Creating a local Contacts group

- 1. Press Contacts.
- 2. **(Optional)** To navigate through **Main menu**, do the following:
 - a. Scroll to **Applications**, and press **Select**.
 - b. Scroll to Contacts, and press Select.
- 3. Press Groups.
- 4. Press NewGroup.
- 5. In the **Enter group name** field, type your group name.

6. Press Save.

Adding a contact to the local group

Before you begin

- · Ensure that your Contacts list is not empty.
- Create minimum one local group to add your contacts.

Procedure

- 1. Press Contacts.
- 2. (Optional) To navigate through Main menu, do the following:
 - a. Scroll to **Applications**, and press **Select**.
 - b. Scroll to Contacts, and press Select.
- 3. Press Groups.
- 4. Select the group, and press **+Members**.
- 5. Scroll to the contact you want to add, and press Add.
- 6. (Optional) To add more contacts, repeat Steps 4 and 5.

Related links

Adding a new contact on page 41

Removing a contact from the local group

Before you begin

Ensure that you have at least one user added to your Contacts list group.

Procedure

- 1. Press Contacts.
- 2. (Optional) To navigate through Main menu, do the following:
 - a. Scroll to Applications, and press Select.
 - b. Scroll to Contacts, and press Select.
- 3. Press **Groups**.
- 4. Scroll to the group, and press **Members**.

The phone displays the list of contacts in the group.

5. Select a contact, and press **Remove**.

The contact will be removed from your Contacts list.

Assigning a ringtone to a contact

About this task

Use this procedure to assign a ringtone to a contact. You can assign a ringtone only to a contact that is saved in the Contacts list.

Procedure

- 1. Press Contacts.
- 2. **(Optional)** To navigate through **Main menu**, do the following:
 - a. Scroll to Applications, and press Select.
 - b. Scroll to Contacts, and press Select.
- 3. Select the contact, and press **Details**.
- 4. Scroll to the active ringtone, and press **Edit**.

The Phone screen displays the Select ringtone window.

- 5. Scroll down to the ringtone that you want to assign, and press **Select**.
- 6. (Optional) To play the ringtone, press Play.
- 7. Press Save.

LDAP Directory

With the LDAP Directory feature, you can search contacts in available Lightweight Directory Access Protocol (LDAP) directories. An LDAP directory option appears at the top of the **Contacts** application list.

You can also select an LDAP directory as your contact search source. This selection disables other search sources. When LDAP directory is an active search source, if you select another search source, this selection disables LDAP directory search.

You can enter multiple search keywords and view up to 49 attributes for each match, such as personal names, addresses, job titles and telephone numbers.

You can add frequently used LDAP contacts to your local **Contacts** with the help of the **+Contact** soft key.

You can combine any found LDAP contact with an existing local contact with the help of the **Combine** soft key.

Setting LDAP Directory as the contact search source

About this task

You can select an LDAP directory as your contact search source to enable searching from the **Contacts** application. This selection disables other available search sources for the **Contacts** application.

Before you begin

Ensure that the feature is activated by the administrator. Contact your administrator for details.

Procedure

- 1. Press Contacts.
- 2. (Optional) To navigate through Main menu, do the following:
 - a. Scroll to Applications, and press Select.
 - b. Scroll to Contacts, and press Select.
- To select LDAP Directory as a source for contact search, press Search > More > Sources.
- 4. Scroll to **LDAP contacts**, and press **Toggle**.

LDAP Directory is now your contact search source. Other sources are disabled. The phone displays the following message: LDAP selected — other search sources disabled.

5. Press Save.

Searching LDAP contacts

About this task

You can search the LDAP directory using the Contacts application on your phone, and specify the LDAP directory as a search source. Alternatively, the user can open the LDAP directory application and refine the search of the LDAP directory directly.

Before you begin

Set LDAP directory as the contacts search source.

- 1. Press Contacts.
- 2. **(Optional)** To navigate through **Main Menu** list, do one of the following:
 - Scroll to Applications, and press Select.
 - Scroll to Contacts, and press Select.
- 3. If you are searching from a LDAP Directory, scroll to **LDAP Directory**, and press **Select**.

The phone displays the list of up to 1000 LDAP contacts. You can use **Up** and **Down** line keys to scroll through the list. If the phone cannot retrieve the contacts from a LDAP server, the phone displays the following message:

No contacts in the group.

- 4. Press **Search**.
- 5. Scroll to the **Search type** option and toggle between **Starts with** and **Contains**.

When you select **Starts with**, the phone returns only the matches that have your query at the start. When you select **Contains**, the phone returns all matches that contain your query.

6. Use the dial pad to enter multiple keywords, separated by a blank space or a comma, into the **Search** field, and press **Search**.

The phone displays the list of matches. If no matches are found in the LDAP directory, the phone displays the following message: No match found.

If more than 20 matches are found in the LDAP directory, the phone displays the following message: We found too many matches. Select from the list or press Back to refine your search.

- 7. **(Optional)** Press **Details** to view contact information for a selected match.
- 8. **(Optional)** Press **+Contact** from the **Details** view to add an LDAP contact to the list of your local contacts.
- 9. **(Optional)** Press **Combine** from the **Details** view to select an existing local contact and merge it with the selected LDAP contact.

Chapter 9: Managing Recents

Call log

Depending on the call type, call log provides the following information about the last 100 calls on your phone:

- Caller name
- Caller number
- · Call time-stamp
- Call duration

Avaya J100 Series IP Phones software version 4.0.3 and later always encrypts the content of the call log file.

When the offline call log feature is disabled in System Manager, if you downgrade the software of your phone to a version earlier than 4.0.3, you will lose the call log details. Contact your administrator for information on retaining the call log details.

Related links

Using Call log (Video)

Making a call from Recents

- 1. Press Recents.
- 2. Use the **Up** and **Down Arrow** keys to select the contact that you want to call.
- 3. Press Call.

Viewing the Recents details

About this task

In the Recents screen, depending upon the call type, you can view the following details of each call:

- · Incoming call icon
- Outgoing call icon
- · Missed call icon
- Name
- Extension number
- Time
- Date
- Duration



Note:

Duration is not available for a missed call.

Procedure

- 1. Press Recents.
- 2. **(Optional)** To navigate through **Main menu**, scroll to the following:
 - a. Applications, and press Select.
 - b. Recents, and press Select.
- 3. Select the call that you want to view.
- 4. Press Details.

The phone displays the details of the selected call.

Deleting a call record from Recents

- Press Recents.
- 2. (Optional) To navigate through Main menu, scroll to the following:
 - a. Applications, and press Select.
 - b. Recents, and press Select.
- 3. Select a number that you want to delete.
- 4. Press **Details**.

- 5. Press **Delete**.
- 6. Select one of the following when the phone prompts for confirmation:
 - **Delete**: To delete the entry.

The phone deletes the number from the call history list.

• Cancel: To cancel and return to the previous menu.

Clearing the Recents list

- 1. Press Recents.
- 2. (Optional) To navigate through Main menu, scroll to the following:
 - a. Applications, and press Select.
 - b. Recents, and press Select.
- 3. Press **Delete**.
- 4. Select one of the following when the phone prompts for confirmation:
 - **Delete**: To delete all entries.
 - Cancel: To cancel and return to the previous menu.

Chapter 10: Managing conference calls

Adding a person to an active call

About this task

You can add participants to an active call to set up a conference call.

Before you begin

Start a call.

Procedure

- 1. During a call, on the Phone screen, press **More** > **Conference**.
 - The phone puts the existing call on hold.
- 2. To make a call to a participant, do one of the following:
 - Dial the phone extension by using the dial pad.
 - Call the person from the Contacts list or the Recents list.
- 3. When the third participant answers the call, press the **Join** soft key.
- 4. To add another person, press Add and repeat Steps 2 and 3.

Related links

Making Conference Calls (Video)

Adding a person on hold to a conference call

About this task

You can add a held call to a conference call.

- 1. On the Phone screen, select your active call.
- 2. Press **Conference** or **Add** button if you are already in a conference.
- 3. Press Held Call soft key to see a list of held calls.
- 4. Select the call on hold that you want to add to the conference.

- 5. Press one of the following:
 - Join
 - OK

The held call is added to the conference call.

Putting a conference call on hold and resuming a call

About this task

Use this procedure to put a conference participant on hold, while other participants continue the conference call.

Procedure

- 1. Press **Hold** soft key during a conference call.
- 2. Do one of the following:
 - Press Resume.
 - Select the call appearance to resume the conference call.

Viewing the details of a conference

About this task

Use this procedure to view the details of the participants on a conference call.

If you cannot, it might be due to the server on which your extension is configured. Contact your system administrator.

- 1. On the Phone screen, select your active call.
- 2. Press **Conference** soft key.
- 3. Do one of the following:
 - Dial the telephone number.
 - · Call the person from the Contacts list.
 - · Call the person from the Recents list.
- 4. When the person answers, press **Join** or **OK** to add the person to the existing call.
- 5. Press **Add** and repeat the steps to add another person to the conference.

6. Press the **Details** button to access the details of the participants.

Dropping or Disconnecting the last participant from a conference call

About this task

You can use this procedure to disconnect the last participant who joined the conference. You cannot disconnect other participants after you disconnect the last participant. You can use this method to disconnect a participant again after you add another participant.

Procedure

- From the phone screen, select your active conference call.
 You will see the **More** soft key.
- 2. Press End Call when the conference is active.

Result

The participant who was added last gets disconnected from the conference.

Related links

Making Conference Calls (Video)

Adding a participant to no hold conference on page 86

Chapter 11: Advanced features

You can access advanced features available on your phone from the Features screen and some advance features from the Applications screen.

Most of the features are configured by the system administrator.

The LED next to the feature name indicates whether the feature is currently on or off.

LED state	Feature Status
Green	On
Red	Off

Accessing the Features screen

About this task

Use this procedure to gain access to the Features screen.

Procedure

- 1. Press Main menu, and scroll to Features.
- 2. Press Select.
- 3. Scroll to see the features that are configured for your extension.

Active call shortcut keys

With Active call shortcut keys, you can use Autodial and Contacts keys as shortcuts during an active call to perform the required action.

The following actions can be performed by pressing these keys:

- Transferring an active call to the selected user immediately or after talking to this user first
- Adding the selected user to an active call to set up a conference call

To configure any of these shortcut actions, contact your system administrator.

Making a call transfer with a shortcut key

About this task

If the caller needs the information that you cannot provide, you can transfer the ongoing call to another user using an Autodial key or a contact as shortcuts.

Note:

The actual key used for a shortcut action depends on the current configuration.

Depending on the configuration set by the system administrator, the phone might make a blind transfer or an attended transfer immediately after the **Transfer** soft key is pressed. Contact your system administrator for more details.

Before you begin

Ensure the following:

- If the configured shortcut is a BLF key, the required user is idle.
- The administrator has set the shortcut action for the key as call transfer.

Procedure

- 1. While on an active call, depending on the configuration, do one of the following on the Phone screen:
 - Press the Autodial or Contact line key.
 - Scroll to the required Autodial line or contact, and press **Transfer**.

The phone displays the Transfer now or talk with [BLF user extension]? confirmation window.

- 2. Press one of the following:
 - Now: To immediately transfer the call to the selected user.

The phone displays the Incoming Call screen with the extension the call was transferred to until the user answers the call.

- Talk: To place the call on hold, and to talk with the user first.
- 3. **(Optional)** If the user does not answer the BLF shortcut transferred call, press one of the following in the Incoming Call screen:
 - **Pickup**: to answer the call on your phone.
 - · Ignore: to end the call.

Making a conference call with a shortcut key

About this task

If you need to include the other agent in your conversation with the caller, you can add an Autodial user or a contact to an active call to set up a conference call.

Before you begin

Ensure the following:

- If the configured shortcut is a BLF key, the required user is idle.
- The administrator has set the shortcut action for the key as conference call. Contact your system administrator for more details.

Procedure

- 1. While on an active call, depending on the configuration, do one of the following on the Phone screen:
 - Press the Autodial or Contact line key.
 - Scroll to the required Autodial line or contact, and press Conf.

The phone puts the existing call on hold.

2. When the user answers the call, press **Join**.

Activating the screen saver

Procedure

- 1. Press Main menu.
- 2. Press Applications.
- 3. Scroll down to **Activate screen saver**, and press **Select**.

Activating Send All Calls

About this task

When Send All Calls (SAC) feature is on, your incoming calls go directly to a predefined coverage number, typically your voice mail. Incoming calls ring once at your extension and then go directly to a number which is set by your system administrator.

You can also turn **Send All Calls** on or off by using the phone Features list.



Note:

Do not enable the SAC feature in case you selected the cover all option for the coverage path. Enabling both features at the same time can cause duplicate entries in the call log.

- 1. Navigate to the Features screen.
- Scroll to choose Do not disturb.

Note:

If you want the feature label to read as **Send all calls**, contact your administrator to relabel the feature name.

3. Press **Select** or **OK** or the corresponding line key to activate the feature.

Automatic Callback

With the Automatic Callback feature, you receive a notification call to connect with the available extension number that was previously busy, unanswered, on another call, or out of coverage.

Setting up Automatic Callback

About this task

Use this procedure to get a notification call when the previously unanswered extension becomes available. You must use this feature only when a call is unanswered.

Before you begin

Ensure that the feature is activated by the administrator. Contact your administrator for details.

Procedure

- 1. Press Main menu, and scroll to Features.
- Press Select.
- 3. Scroll to Automatic Callback, and press Select.

When you end the callback call, the phone deactivates the feature automatically.

Autodialing a pre-assigned number

About this task

The autodialing feature enables you to quickly call the pre-assigned numbers. While your phone is off-hook, on-hook, and from line key. Your system administrator might set up few frequently called numbers, such as the IT Help Desk for autodialing. These numbers are displayed on the phone screen.

Before you begin

Ensure that your system administrator has set up few frequently called numbers to use this feature.

Procedure

Do one of the following to autodial a number:

- If your phone is on-hook, choose the number which appears on your phone screen, and press the **Call** soft key or the **OK** button.
- If your phone is off-hook, the autodialing screen appears, press the required line key.
- You can choose a number from the Expansion Module and press the required line key.

Blocking your extension from displaying during calls

About this task

You can override the system (default) setting to display your extension on outgoing calls. Use the Calling Party Number Blocking feature to prevent your number from displaying.

Procedure

- 1. From the Phone screen, access the Features screen.
- 2. Select CPN Block.
- 3. Enter the extension number you do not want the called party to see.
- 4. Press **Enter** or **OK** to start calling party number blocking.

Bridged Call Appearance

Bridged Call Appearance is a unique extension number that is shared among multiple users to communicate through a single call appearance. You can make, receive, and join a call on behalf of the owner by using the bridged appearance. The bridged appearance might display the bridge owner's identity on the receiver's display screen.

Making a call on a bridged line

About this task

Use this procedure to make a call on another user's bridged line.

Before you begin

Ensure that the required bridged line is idle.

Procedure

1. Press the line key of the bridged number that you want to use.

2. Enter the number by using the dial pad.

The phone initiates the call when the inter digit timer times out.

Answering a bridged line call

About this task

When you receive a call from a bridged line, the Phone screen displays the bridge owner's identity. If you receive more than one bridged call, the Phone screen highlights the recent bridged call.

Procedure

- 1. Do one of the following:
 - · Lift the handset.
 - Press Speaker.
 - Press the Answer soft key.
- 2. **(Optional)** For multiple bridged call appearances, do the following:
 - a. Press the line key of the bridged number that you want to answer.
 - b. Continue with Step 1.

Joining a call on a bridged line

Procedure

On the phone, do one of the following:

- Press the line button with the active call.
- Select an active bridge line number, and press Bridge.

Note:

On Avaya J179 IP Phone, do not use **Headset**, **Handset** or **Speaker** softkeys to join the call on a bridged line. Pressing **Headset**, **Handset** or **Speaker** opens the Dial screen. To cancel dialing and to press the required line button for joining a call, press the **Headset**, **Handset** or **Speaker** softkey again.

Busy Indicator

With the Busy Indicator (BI) feature, you can do the following:

View the status of other users in the network

- Make quick calls to the monitored users
- Transfer calls by pressing the Busy Indicator line key
- · Make conference calls with BI users

The icon next to the Busy Indicator line key displays the current status of the monitored user (idle or busy).

The user status is also reflected by the indication of LEDs integrated into the corresponding line keys.

You can relabel and move a Busy Indicator line key from the Phone keys customization menu. However, you cannot add or delete Busy Indicator keys configured on your phone. Contact your system administrator if you want to add more BI line keys or delete the existing ones.

Related links

<u>Customizing phone keys</u> on page 103
<u>Busy Indicator icons and LED indication</u> on page 62

Busy Indicator icons and LED indication

Busy Indicator icons look the same as Presence "Available" and "On a call" icons but they might differ depending on the phone or the button module model.

The following table displays the Busy Indicator icons and LED indication for Avaya J169/J179 IP Phone, JBM24 Button Module, and Avaya J100 Expansion Module.

The icons of Avaya J169 IP Phone and Avaya J179 IP Phone look similar, but Avaya J169 IP Phone has grayscaled icons and Avaya J179 IP Phone has color icons.

State	Phone icons	JBM24 Button Module icons	Avaya J100 Expansion Module icons	Red LED for the line key	Green LED for the line key
Idle		~	②	Off	Off
Busy	<u>C</u>	©	C	Off	On

Related links

<u>Customizing phone keys</u> on page 103 <u>Busy Indicator</u> on page 61

Busy Indicator call operations

Making a call to a monitored user

About this task

You can make a quick call to monitored users, for example, when you want to provide direct instructions to them.

Procedure

Do one of the following:

- On the Phone screen, scroll to the required Busy Indicator line, and press Call.
- · Press the required Busy Indicator line key.

Making a conference call with a monitored user

About this task

Use this procedure to add a monitored user to an active call to set up a conference call.

Procedure

1. During an ongoing call, press **More > Conf**.

The phone puts the call on hold, and displays the Select a participant notification.

- 2. Press the **Phone** key.
- 3. Do one of the following:
 - · Scroll to the required Busy Indicator line, and press Call.
 - Press the required Busy Indicator line key.
- 4. When the monitored user answers the call, press Join.

Call Transfer to a monitored user

Ongoing calls can be transferred to a user on the Busy Indicator line. This transfer is managed similarly to Call Transfer to a phone extension.

You can transfer a call immediately (blind transfer) or after making a consultative call to the monitored user (attended transfer).

Related links

Call Transfer on page 74

Making a blind transfer to a monitored user

About this task

Use this procedure to transfer immediately an active call to a monitored user.

- 1. During an active call, press **Transfer**.
- 2. Do one of the following:
 - Press the Busy Indicator line key corresponding to the user you want to transfer the call to.
 - Press the **Phone** key, scroll to the required Busy Indicator line, and press **Select**.

The phone displays the Transfer now or talk with [BI extension number]? window.

3. Press Now.

Your call is transferred to the monitored line.

Making an attended transfer to a monitored user

About this task

Use this procedure to transfer an active call to a monitored user by talking to this user first.

Procedure

- 1. During an active call, press Transfer.
- 2. Do one of the following:
 - Press the Busy Indicator line key corresponding to the user you want to transfer the call to.
 - Press the **Phone** key, scroll to the required Busy Indicator line, and press **Select**.

The phone displays the Transfer now or talk with [BI extension number]? window.

3. Press Talk.

The current call is placed on hold, and a call to the monitored user is established.

4. To end your consultative call and to transfer the held call, press **Complete**.

Calendar

With the Calendar feature, you can access the Microsoft[®] Exchange Server calendar on your phone. You can also view and set a reminder for meetings or appointments.

When Exchange Calendar is active, appointments are displayed in the order of their start times and are removed once the meeting time expires. Calendar information is updated whenever you log in to your phone, change calendar settings, or access the Calendar.

Accessing calendar

About this task

Use this procedure to open calendar on your phone.

Before you begin

Ensure that your administrator has activated **Exchange credentials** on your phone.

Procedure

- 1. Press Main menu.
- 2. Scroll to **Applications**, and press **Select**.
- 3. Scroll down to Calendar, and press Select.

If you are accessing calendar for the first time, the phone displays Exchange credentials screen to access your Microsoft® Exchange Server.

Configuring the Microsoft® Exchange Server calendar

Before you begin

- Ensure that the feature is activated by the administrator. Contact your administrator for details.
- Get the following details from your administrator:
 - User name
 - Password
 - Domain name

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to **Applications**, and press **Select**.
- 4. Scroll to Exchange credentials, and press Select.
- 5. Type the following details:
 - Exchange username: Enter your email ID.
 - Exchange password: Enter your password.
 - Exchange domain: Enter the domain name, for example, avaya.com.
- 6. (Optional) To enable or disable Name/Password Prompt, do one of the following:
 - Toggle: To enable or disable the prompt.
 - The Right Arrow key: To enable the prompt.
 - The **Left Arrow** key: To disable the prompt.
- 7. Press Save.

Reviewing your Calendar event

About this task

Use this procedure to view your calendar appointments. You can set the **Enable Exchange Calendar** and **Enable Reminder** option to **Yes** to get a pop-up reminder of your upcoming calendar appointments.

Before you begin

Ensure Microsoft® Exchange is configured on your phone.

Procedure

- 1. Press Main menu.
- 2. Scroll to **Applications**, and press **Select**.
- 3. Scroll to Calendar, and press Select.

The phone displays the appointments in the start-time order.

- 4. To scroll from one appointment to another, press one of the following:
 - The Up Arrow key.
 - The **Down Arrow** key.
- 5. Select the calendar event, and press one of the following:
 - Call: To call the extension number available in the appointment.
 - Details: To view the details of the calendar event.
 - Month: To view the Calendar Event Month screen.
 - Exit: To exit from the event screen.
- 6. In the Calendar Event Month screen, press one of the following:
 - Today: To view calendar event of the current date.
 - Day: To view calendar event of the selected day.

Related links

Enabling and disabling Exchange calendar on page 108 Enabling and Disabling Calendar reminder on page 109

Call forwarding

With the Call forwarding feature, you can divert incoming calls to another number.

The phone supports the following Call forward types:

- Call forward: Diverts all incoming calls to another number.
- Call forward Busy: Diverts incoming calls to another number if you are on a call.
- Call forward No Answer: Diverts incoming calls to another number when you do not answer the call within the set time.

Enhanced Call forward

The Enhanced Call forward feature is used to set rules on call forwarding. You can set the rules by entering the internal and external phone numbers in the corresponding Call forward types.

Example

For example, you enabled the Call forwarding feature on your phone and the caller dials your extension number. In this case, your phone will redirect that incoming call to the assigned call forwarding number.

Forwarding a call to another extension

About this task

Use this procedure to forward incoming calls to a specified number.

In the IP Office environment, this feature is supported using short code dialing. Contact your system administrator for the list of short codes.

Before you begin

Ensure that the feature is activated by the administrator. Contact your administrator for details.

Procedure

- 1. Press Main menu.
- 2. Scroll to **Features**, and press **Select**.
- 3. To enable Call Forward feature, scroll to one of the following options:
 - Call Forward
 - Call Forward-Busy
 - · Call Forward-No Answer
- 4. Press Select.
- 5. In the **Destination** field, enter the number where you want to forward the incoming calls.
- 6. Press Enter.

The phone generates a confirmation tone and returns to the Features screen.

7. To disable any of the Call Forward features, go to the respective screen and press **Select**.

Setting enhanced call forwarding

About this task

You can use this feature to forward the incoming calls on your phone to various destination numbers based on the call type and call state.

Before you begin

Ensure that the feature is activated by the administrator. Contact your administrator for details.

Procedure

- 1. Press Main menu.
- 2. Scroll to **Features**, and press **Select**.
- 3. Scroll to Enhanced Call Forward, and press Select.
- 4. Select the required rules from the following list, and enter the corresponding numbers.
 - · Forward all calls:
 - Internal [Enter Number]
 - External [Enter Number]
 - Forward when busy:
 - Internal [Enter Number]
 - External [Enter Number]
 - · Forward when no answer:
 - Internal [Enter Number]
 - External [Enter Number]

If you have configured a number for any of the rules, the phone displays that number instead of the text Enter Number.

5. Press Save.

Editing a rule for enhanced call forwarding

About this task

With the enhanced call forwarding feature, you can forward the incoming calls on your phone to various destination by setting the rules as per your requirements. To edit the already set rules, you can use the following procedure.

Before you begin

Ensure that the Enhanced Call Forward feature is activated by your administrator.

Procedure

1. Press Main menu.

- 2. Scroll to Features, and press Select.
- 3. Scroll to Enhanced Call Forward, and press Select.
- 4. Select the rule that you want to edit, and press **Edit**.
- 5. Enter the destination number.
- 6. Press Save.

Turning off rules for enhanced call forwarding

About this task

With the enhanced call forwarding feature, you can forward the incoming calls on your phone to various destination by setting the rules as per your requirements. To turn off the already set rules, you can use the following procedure.

Before you begin

Ensure that the Enhanced Call Forward feature is activated by your administrator.

Procedure

- 1. Press Main menu.
- 2. Scroll to **Features**, and press **Select**.
- 3. Scroll to Enhanced Call Forward, and press Select.
- 4. Do one of the following:
 - To turn off a rule, select the rule, and press **Turn off**.
 - To turn off all rules, press All off.
- 5. Press Save.

Call forwarding to your cell phone using EC500

About this task

Use this procedure to forward calls from your Avaya deskphone to your personal phone.

Before you begin

- Ensure that the feature is activated by the administrator. Contact your administrator for details.
- Ensure that the system administrator sets your personal phone number as your destination number.

- 1. Press Main menu, and scroll to Features.
- 2. Press Select.

3. Scroll to **EC500**, and press **Select**.

Calling in your intercom group

About this task

Use this procedure to call a specific extension or an intercom group.

Before you begin

Ensure that the feature is activated by the administrator. Contact your administrator for details.

Procedure

- 1. Press Main menu, and scroll to Features.
- 2. Press Select.
- 3. Scroll to **Dial Icom**, and press **Select**.

The intercom group number shows next to the Dial Intercom feature.

- 4. Press the number that corresponds to the destination extension.
- 5. Press Enter.

Example

Auto icom 2 3: The first number denotes the intercom group number for the Dial Intercom feature. The next number denotes the extension your administrator has predefined as your automatic intercom destination extension.

Call Parking

With the Call Parking feature, you can put an active call on hold and resume the call from any other phone in your organization. The administrator must activate this feature in your phone to park a call in your extension. You can dial your extension number from any other phone to retrieve the call.

Related links

Call Parking (Video)

Parking a call

About this task

Use this procedure to park an active call on your phone extension.

Before you begin

Ensure that you are on a call.

Procedure

- 1. Press Main menu.
- 2. Scroll to **Features**, and press **Select**.
- 3. Scroll to Park Call, and press Select.

Related links

Call Parking (Video)

Unparking a call

About this task

Use this procedure to unpark the call from another phone.

Before you begin

Ensure that you have parked a call on your extension.

Procedure

- 1. Press Main menu.
- 2. Scroll to **Features**, and press **Select**.
- 3. Scroll to Unpark Call, and press Select.
- 4. Enter your phone extension number.
- 5. Press Select.

Related links

Call Parking (Video)

Call Pickup

With the Call Pickup feature, you can answer an incoming call on behalf of a pickup group member. The administrator must add you to a Call Pickup group extension so that you can redirect an incoming call of your group member to your phone. When Call Pickup feature is active on your phone displays the incoming call of your group member on a call appearance line.

Avaya J100 Series IP Phones support the following three ways of Call Pickup in Avaya Aura[®] Communication Manager.

 Call Pickup: Allows you to answer a call on behalf of a member of the same Call Pickup group.

- Call Pickup Extended: Allows you to answer a call of another pickup group by dialing the group extension number of that Call Pickup group.
- Call Pickup Directed: Allows you to answer a call of a member of another pickup group by dialing the extension number of the ringing phone.

Ensure that your administrator configures the call pickup feature for your extension.

When Call Pickup feature is active Avaya Aura[®] Communication Manager automatically searches for the incoming calls in the associated groups to make the call connection.

Answering a call for a Call Pickup group member

About this task

With the Call Pickup feature, you can answer an incoming call on behalf of a another call pickup group member. Use this procedure to answer a call for a group member.

Before you begin

Ensure that the feature is activated by the administrator. Contact your administrator for details.

Procedure

- 1. Press Main menu, and scroll to Features.
- 2. Press Select.
- 3. Scroll to **Call Pickup**, and press **Select**.
- 4. To answer a call, do one of the following:
 - · Lift the handset.
 - Press Answer.
 - · Press OK.
 - · Press Speaker.

Answering a call in the same Call Pickup group

About this task

With the Call Pickup feature, you can answer an incoming call on behalf of a pickup group member. Use this procedure to answer a call in the same call pickup group.

Before you begin

Ensure that the feature is activated by the administrator. Contact your administrator for details.

- 1. Press **Main menu**, and scroll to **Features**.
- Press Select.

- 3. Scroll to Call pickup extended, and press Select.
- 4. To answer a call in the same pickup group, enter the extension number of the ringing phone.
- 5. Press **Enter**.

Answering a call using the extension number

About this task

With the Call Pickup feature, you can answer an incoming call on behalf of a pickup group member. Use this procedure to answer a call of another pickup group by using the extension number.

Before you begin

Ensure that the feature is activated by the administrator. Contact your administrator for details.

Procedure

- 1. Press Main menu, and scroll to Features.
- Press Select.
- 3. Scroll to Call pickup directed, and press Select.
- 4. To answer a call of another pickup group, dial the extension number of the ringing phone.
- 5. Press Enter.

Call recording

With the Audix Record feature, you can record your current call.



Some countries, states, and localities have laws that determine if and under what circumstances you can record telephone conversations. Before using the Audix Record feature, you must understand and comply with these laws.

Recording a call

Before you begin

Ensure that the feature is activated by the administrator. Contact your administrator for details.

Procedure

1. Press Main menu, and scroll to Features.

- 2. Press Select.
- 3. Scroll to Audix Record, and press Select.
- 4. Disconnect the call to stop recording.

Call Transfer

With the Call Transfer feature, you can transfer your call to another destination number.

The types of Call Transfer are:

- Consultative transfer: Transferring a call by connecting a call with the transfer recipient.
- Blind transfer: Transferring a call without connecting a call with the transfer recipient.

Related links

Handling multiple lines (Video)

Making a consultative transfer

About this task

Transfer a call by connecting a call with the transfer recipient.

Procedure

1. While on an active call, press **Transfer** soft key.

The phone displays the Enter transfer destination screen.

The first call is placed on hold.

- 2. Do one of the following and then press the Call soft key:
 - · Dial the number to transfer the call.
 - · Search for the number in Contacts or Recents.
- 3. To initiate a consultative transfer, press **Talk**.

The call transfer recipient's phone starts ringing.

- 4. Do one of the following:
 - Press **Complete** after the recipient answers the call.

The call transfer is complete. This is also called attended transfer.

Press Complete after the recipient's number starts ringing.

The call transfer is complete. This is also called unattended transfer.

Related links

Handling multiple lines (Video)

Making a blind transfer

About this task

Use this procedure to transfer an active call without connecting a call with the transfer recipient.

Procedure

1. While on an active call, press **Transfer**.

The phone displays the Enter Transfer Destination screen.

- 2. Do one of the following and then press the **Call** soft key:
 - Dial the number to which you want to transfer the call.
 - · Search for the number in the Contacts or Recents list.
- 3. To initiate a blind transfer, press Now.

The call transfer is complete.

Related links

Handling multiple lines (Video)

Crisis alert station

Table 1: Participants in a crisis alert

Participant	Description
Emergency caller	A person in your organization who calls the emergency number.
Crisis alert watcher	A person in your organization who gets an alert notification immediately after an outgoing emergency call.

Crisis alert station

In a crisis alert station, when an emergency caller calls an emergency number, all the crisis alert watchers receive a notification about this, so that they can attend to the caller immediately. The system administrator assigns the crisis alert watchers.

During a crisis alert, the crisis alert watchers receive the following types of notifications:

- Crisis alert view: A pop-up screen displays the emergency caller name and the call origination extension. The screen is visible until the watcher acknowledges it.
- Audio alert: An alert tone plays continuously until the watcher acknowledges it.
- Visual alert: The green feature LED flashes.

The system administrator configures the crisis alert feature. Depending upon the feature configuration, the crisis alert watchers receive the crisis alert notification in one of the following mode:

- Single user mode: When any one of the crisis alert watcher acknowledges the crisis, the alert stops on the IP Phones of the other crisis alert watchers.
- Every user mode: Each crisis alert watcher acknowledges the crisis for the alert to stop at their respective IP Phone.

Acknowledging the crisis alert

About this task

As a crisis alert watcher, you can acknowledge a crisis alert when you receive the following notifications on your phone:

- Alert tone
- LED flashes
- The screen displays the emergency caller information.

If the feature is configured in single-user mode, when you acknowledge the alert, the alerting at the other watcher's IP Phone stops.

You can use the same procedure to acknowledge the crisis alert even when the phone is locked.

Before you begin

Ensure that your system administrator designates you as a crisis alert watcher.

Procedure

- 1. The phone screen displays the emergency caller name and extension.
- 2. Press **OK**.
- 3. The phone screen displays the details of an emergency caller.

If there is a new crisis alert while you are viewing the details of the current alert, then the phone plays the alert tone again. To view the new crisis alert details, press **Back**.

Emergency caller information

The Phone screen displays the following details of an emergency caller:

Field	Description
Extension	The emergency caller extension.
The following fields will display details only if Avaya Aura [®] Communication Manager has this information.	
User name	The emergency caller name.

Table continues...

Field	Description
Date	The crisis occurrence date.
Time	The crisis occurrence time.
Zone	The crisis occurrence zone.
Crisis user room	The emergency call origination room.
Crisis user floor	The emergency call origination floor.
Crisis user building	The emergency call origination building.

Stopping the crisis alert

About this task

During a crisis alert, the phone plays the alert tone, the LED flashes, and the screen displays the emergency caller information. As a crisis alert watcher, in every user mode, you have to stop the alerts on your phone. In single-user mode, the alerts will stop on your phone if any one of the other crisis alert watchers stops the alerts before you do.

Before you begin

Ensure your that system administrator assigns you as one of the crisis alert watchers.

- Crisis alert view: press the **OK** soft key to stop the view.
- Audio alert: Press the **OK** soft key if you are in the crisis alert view, else press the Crisis Alert feature line key to stop the audio alert.
- Visual alert: Press the Crisis Alert feature line key to stop the LED flashing.

Acknowledging the crisis alert after an error in the first acknowledgment

About this task

Due to some technical issues, if there is an error in the acknowledgment process, the phone will display an error message while the alert tone continues to play. You can acknowledge this alert again.

Before you begin

Ensure that your system administrator designates you as a crisis alert watcher.

- 1. Press the Main menu.
- 2. Scroll to **Features**, and press **Select**.

- 3. Scroll to Crisis Alert, and press Select.
- 4. The Phone screen displays the details of an emergency caller.

If there is a new crisis alert while you are viewing the details of the current alert, then the phone plays the alert tone again. To view the new crisis alert details, press **Back**.

Displaying your extension on outgoing calls

About this task

If you used the Calling Party Number (CPN) Block feature to block displaying your extension on the calls you make, you can change it back using CPN Unblock. CPN Unblock allows parties you call see your extension.

Procedure

- 1. From the Phone screen, access the Features screen.
- 2. Select CPN Unblock.
- 3. Enter your extension number.
- 4. Press **Enter** or **OK** to stop calling party number blocking.

Excluding others from bridging on to your call

About this task

Use the Exclusion feature to prevent others who are bridged to your extension from bridging onto a specific call. You can activate exclusion only during an active call.

Before you begin

Ensure that the feature is activated by the administrator. Contact your administrator for details.

Procedure

- 1. Press **Main menu**, and scroll to **Features**.
- Press Select.
- 3. Scroll to **Exclusion**, and press one of the following:
 - Select
 - Corresponding line button

When you activate Exclusion during a call, all parties except you, the calling and the called party are dropped from the call.

Extending a call to your cell phone

About this task

Use this procedure to forward an ongoing call to your cell phone by using the EC500 feature. When you answer the extended call on your cell phone, the call remains active on your office phone. Later you can switch back to your office phone to continue the call.

Before you begin

- Ensure that the feature is activated by the administrator. Contact your administrator for details.
- Ensure that EC500 is configured on your mobile phone.
- Ensure that your administrator sets your personal phone number as your destination number.

Procedure

- 1. Press Main menu, and scroll to Features.
- 2. Press Select.
- 3. Scroll to Extend Call, and press Select.
- Press OK.

You will receive a call on your cell phone to answer the extended call.

Hunt Group Busy

Using the Hunt Group Busy feature, users can opt-in or opt-out of the calls specific to the hunt group. A hunt group is a group of users who handle the similar types of calls. A user can be a part of multiple hunt groups.

The Features screen displays the **Hunt Group Busy** buttons. Each **Hunt Group Busy** button corresponds to a specific hunt group. The **Hunt Group Busy** button label includes a unique four-digit index for each group.

Using Hunt Group Busy

About this task

Use the **Hunt Group Busy** buttons on the Features screen to manage the calls from a particular hunt group.

- 1. To stop receiving calls from a particular hunt group, press the corresponding **Hunt Group Busy** button.
- 2. To turn off the Hunt Group Busy feature for a particular hunt group and start receiving calls, press the corresponding **Hunt Group Busy** button.

Interrupting a call with a whisper page

About this task

Use this procedure to make an announcement to a person on another extension who is active on a call. The person who is paged can only hear the announcement.

Before you begin

Ensure that the feature is activated by the administrator. Contact your administrator for details.

Procedure

- 1. Press Main menu, and scroll to Features.
- 2. Press Select.
- 3. Scroll to Whisper page, and press Select.
- 4. Enter the extension number that you want to call.
- 5. Press Enter.
- 6. Deliver the message when your call is received.

Example

You are on a call with users A, B, and C. You have an urgent message for user A. When you use the Whisper page feature to deliver a message to user A's extension, all three users hear the tone that signals the page, but only user A hears the message.

Limit Incoming Calls

With the Limit Incoming calls feature, you can limit the number of concurrent calls and change the call appearance. When you activate the feature, the multiple call appearance changes to a single call appearance, and the following is observed:

- When you are on a call, if you receive another call, the second caller gets a busy tone. If the Busy Station Call Log feature is enabled, this call is logged as a missed call in the call log.
- In Autodial mode, when you dial a number, if your phone receives a call, the phone logs this incoming call as a missed call in the call log.

Activating Limit Incoming Calls

About this task

You can activate the Limit Incoming Calls feature to limit the number of incoming calls and change multiple call appearance to a single call appearance.

Before you begin

Ensure that your administrator has configured the Limit Incoming Calls feature for your extension.

Procedure

- 1. Press the **Main menu**.
- 2. Scroll to **Features**, and press **Select**.
- 3. Scroll to Limit incoming calls, and press Select.

Result

The Limit Incoming Calls feature will be activated.

Deactivating Limit Incoming Calls

About this task

You can deactivate the Limit Incoming Calls feature to remove the limit on number of incoming calls and change a single call appearance to multiple call appearance.

Procedure

- 1. Press the Main menu.
- 2. Scroll to **Features**, and press **Select**.
- 3. Scroll to Limit incoming calls, and press Select.

Result

The Limit Incoming Calls feature will be deactivated.

Long-term acoustic exposure protection

Avaya J100 Series IP Phones have the long-term acoustic exposure protection to prevent the users from getting acoustic shocks. This feature reduces the loud volume of the conversations on the phone call to permissible acoustic limits. The user can set the permissible acoustic limit to dynamic or predefined static values. If a dynamic setting is selected, the feature activates itself and gradually reduces the loud volume of the phone conversations to prevent from reaching the damaging decibel levels.

Long-term acoustic exposure protection feature satisfies OSHA, ETSI and employee health safety requirements.

Important:

Only L100 Series Headsets with RJ9 connector support long-term acoustic exposure protection when the headset profile is set to **Profile1**.

Configuring Long term acoustic protection

About this task

Long-term acoustic protection feature reduces the loud volume of the conversations on the phone call to permissible acoustic limits, you can configure the long-term acoustic exposure protection for your headset.

Before you begin

Ensure you set the headset profile to Profile1, and use L100 Series Headsets.

Procedure

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to **Audio** settings, and press **Select**.
- 4. Scroll to Long term acoustic protection, and press Select.
- 5. Choose one of the following and press **Select**:
 - Default: Sets the acoustic protection values to one of the following options that your administrator sets:
 - Dynamic
 - 8 hours
 - 4 hours
 - Off

Administrator configured value will be chosen as the default value.

- Off: Sets the acoustic protection off.
- Dynamic: Sets the acoustic feature to Dynamic, which activates itself and gradually reduces the loud volume of the phone conversations to prevent from reaching the damaging decibel levels.
- 4 hours: Sets the acoustic protection for 4 hours.
- 8 hours: Sets the acoustic protection to 8 hours.
- 6. Press Save.

Related links

Setting a headset profile on page 116

Multiple Device Access

With the Multiple Device Access (MDA) feature, you can register up to 10 SIP devices with the same extension to transfer active calls between devices.

This feature is available only in an Avaya Aura[®] environment. Multiple Device Access is configured on Avaya Aura[®] Session Manager.

MDA limitations

The limitations for Multiple Device Access are the following:

- There is no audio or visual alerting for the third incoming call if two call appearances are already in use.
- When you receive an MDA indication, press the **Phone** button to view the details and join the bridged call.

Related links

Handling calls and conferences using Multiple Device Access on page 33 Adding a participant to no hold conference on page 86

Using URI dialing to make a call

About this task

Use this procedure to dial an extension with the format username@host where the name of the host includes one of the following:

- IPv4 address
- Fully qualified domain name

Before you begin

Ensure that the Manual dialing feature is enabled on your phone.

Procedure

- 1. Enter the URI extension by using relevant input method for uppercase and lowercase letters, and numbers.
- 2. Press the **Call** soft key to make the call.

Related links

Setting the dialing mode on page 99

Making a priority call

About this task

Use the Priority Calling feature to provide a special type of internal call alerting for the users. The called party hears a distinctive ringing when the calling party uses Priority Calling.

Procedure

- 1. Before dialing, press **Main menu**.
- 2. Scroll to Features, and press Select.
- 3. If necessary, scroll down to **Priority Call**, and press **OK**, or just press the corresponding line button.
- 4. Enter the extension you want to call.
- 5. Press **Enter** or **OK** to immediately start dialing the priority call to the extension where the call appearance will show the incoming call as a priority call.

Multicast Paging

With the Multicast Paging feature, you can receive a page that will be automatically played on the phone. If configured by the system administrator, you can send a multicast page to a group of phones in the network.

An incoming multicast page is played on the phone speaker. When the page is played, the Phone screen displays the Page from <group name> notification during the whole time of transmission.

All configured multicast groups that you can send a page to are available in the Features menu. You can add, move or delete the multicast page keys from the Phone screen by the common customization procedure.

Active calls with a lower priority than the multicast page are put on hold, all lower-priority incoming calls are ignored.

A multicast page is ignored if the agent is on an active call and has the Do Not Disturb status, or making an emergency call.

Related links

Customizing phone keys on page 103

Sending a multicast page

About this task

You can send a multicast page to a group of users by activating the Multicast Paging group on the Phone screen. If the required group is not added on this screen, you can access all multicast page groups configured for your phone in the Features menu.

Procedure

- 1. Do one of the following:
 - · Lift the handset.
 - Press Speaker.
 - · Press Headset.
- 2. (Optional) If you use the handset, press End Call to cancel dialing.
- 3. On the Phone screen, scroll to the required multicast page group, and press **Select**.

The phone displays the Paging <group name > box.

- 4. To end the multicast page, do one of the following:
 - Press End Call.
 - If you use the handset as an audio device, hang up.

No Hold Conference

With the No Hold Conference feature, you can add participants to your call while continuing your active conversation. The No Hold Conference feature lets you create a conference call without putting any call participant on hold.

For example, if you press the administered **No Hold Conference** button and then dial an extension the participant that answers the call joins the no hold conference.

Using the **No Hold Conference** button you can add more participants to the no hold conference.

The administrator can pre-configure only one number on System Manager. When you press the **No Hold Conference** button, the call is placed to the pre-configured number when the participant answers the call joins the no hold conference.

If the participants do not answer the call within the configured time-out duration Avaya J100 Series IP Phones will display the appropriate message on the phone screen.

Adding a participant to no hold conference

About this task

You can add participants to your call while continuing your conversation without interruption. You can add up to six participants in the no hold conference call.

Before you begin

Ensure that the administrator has activated the no hold conference feature, and you are on an call.

Procedure

- 1. During an active call, on the phone screen, press Main menu > Features.
- 2. Press No Hold Conference.
- 3. You can add users to a no hold conference by using one of the following methods:
 - If an extension number is pre-configured by your administrator, you can press **Select**.
 - If the extension number is not pre-configured, you will get a Dial screen to enter the extension number, press **OK**.
- 4. To add more participants to the existing no hold conference, repeat Steps 2 and 3.

Related links

<u>Handling calls and conferences using Multiple Device Access</u> on page 33 <u>Multiple Device Access</u> on page 83

Dropping or Disconnecting the last participant from a conference call on page 55

Precedence call

You can override other calls by making a priority call with precedence. You can manually dial the extension number or select the extension from **Contacts** or **Recents**. The precedence level is valid for only one call session. The call precedence levels are:

- FO: Flash Override. Highest precedence.
- FL: Flash.
- IM: Immediate.
- PR: Priority.
- Routine: Lowest precedence. Routine is highlighted on the call session line if no call is made within five minutes.

You can start a precedence call from Bridged Appearance, but not from the Team button.

Making a precedence call by using the Main menu

Procedure

- 1. Press Main menu.
- 2. Scroll to **Applications**, and press **Select**.
- 3. Select Call Priority.
- 4. On the Precedence Selection screen, select the precedence level.
- 5. Dial the extension from one of the following:
 - Contacts
 - Recents
 - · The dial pad

Making a precedence call by using dial plan configuration

About this task

Use this procedure to make a precedence call manually by dialing the extension number.

Before you begin

Ensure that the Dial plan is configured on the Local Session Controller or Enterprise Session Controller with the Feature Access Code (FAC).

Procedure

- 1. Lift the handset or press one of the following:
 - Speaker
 - Headset
 - Corresponding line button
- 2. Dial the FAC followed by the extension number.

Pre-configuration of keys

With the Pre-configuration of keys feature enabled, the Phone screen displays a pre-determined set of phone keys for accessing features, applications, and line appearances. Phone extensions for autodialing can be also added and accessed with this feature.

The phone configuration is forced by the system administrator, and you cannot change the mapping or labels of pre-configured keys.

Contact your system administrator if you need to replace, move, or relabel the pre-configured keys.

Presence

With the Presence feature, you can monitor the status of your contacts in real time. The administrator must activate this feature to display presence information on your Phone screen.

You can change your status manually so that other users can see your availability for communication.

Viewing the Presence status of your contacts

Before you begin

- Ensure that the feature is activated by the administrator. Contact your administrator for details.
- Set Track Presence option to Yes when you add or edit a contact in the Contacts list.

Procedure

- 1. Press Contacts.
- 2. (Optional) To navigate through Main menu, do the following:
 - a. Scroll to **Applications**, and press **Select**.
 - b. Scroll to Contacts, and press Select.
- 3. Scroll to the required contact.

The phone displays the corresponding Presence icon of the contact.

Related links

Adding a new contact on page 41

Changing your Presence status

Before you begin

Ensure that the feature is activated by the administrator. Contact your administrator for details.

- 1. Press Main menu.
- 2. Scroll to Applications, and press Select.
- 3. Scroll to My Presence, and press Select.

- 4. (Optional) Scroll to Automatic.
- 5. Scroll and press **Select** to choose one of the following:
 - Available
 - Busy
 - Away
 - Do not Disturb
 - Out of Office
 - Offline
- 6. Press Save.

Related links

Presence icons on page 29 Presence icons on page 29

Retrieving a voice message

About this task

Use this procedure to listen to your voicemail messages. Few voicemail configuration has the web interface to access it, please contact your administrator for more information.

Before you begin

- Ensure that the system administrator configures the voicemail for your extension.
- Obtain the user ID and password of your voicemail from your system administrator.

Procedure

- 1. To log in to your voicemail, press the **Message** button.
- 2. Follow the voice prompts to playback your voice messages.

Related links

Using Voice Mail (Video)

Configuring your Voice Mail Password from the Web Interface (Video)

Accessing Voice mail through the Voice mail Web Interface (Video)

Service Observe

With the Service Observe feature, as a supervisor, you can monitor a phone call to observe the call quality. You can also provide on the job training by coaching the agent during the service observe.

You can activate the feature from the phone.

The Service Observe feature has the following modes:

- Basic: You can activate the feature in Listen-only mode. You can switch from Listen-Only mode to Talk mode if your administrator configures it.
- No-Talk: You can activate the feature in Listen-only mode and cannot switch to Talk mode.
- Next Call: You can activate the feature in Listen-only mode for the next call. You can switch from Listen-Only mode to Talk mode if your administrator configures it.
- By-Location: You can activate the feature in Listen-only mode for a Vector Directory Number (VDN). You must provide a VDN and a location ID. You can observe the call only when the agent at the required location connects to a call. You can switch from Listen-only mode to Talk mode if your administrator configures it.

Depending on your requirement you can use the following options:

- Listen-only: In the Listen-only mode, you can silently monitor the call.
- Talk: In the Talk mode, you can talk to the agent and the caller.

Use the Computer Telephony Integration (CTI) client to remotely activate or deactivate the Service Observe feature. For information on using the CTI client, see Avaya Aura[®] Application Enablement Services documentation.

Activating Service Observe

About this task

You can activate the Service Observe feature to observe a call to an IP Phone, agent, or a Vector Directory Number (VDN). The phone displays the observing modes depending on the configuration made by your administrator.

- 1. Press Main menu. and scroll to Features.
- Press Select.
- Scroll down to Service Observe.
- 4. Press Select.
- 5. Select one the following options:
 - Basic
 - No-Talk
 - Next Call
 - By-Location
- 6. Enter the extension of the phone or agent or the VDN that you want to observe and press **Enter**.

Deactivating Service Observe

About this task

You can deactivate the Service Observe feature by using any one of the items in the procedure.

Before you begin

Ensure that the Service Observe feature is active.

Procedure

To deactivate Service Observe, perform one of the following:

- While on the Call Observation line, press the **EndCall** softkey.
- · Answer an incoming call.
- · Select an idle Call Appearance line.
- · Change to an on-hold call.
- · Go on-hook.
- Log out.

Assisting an agent on an observed call

About this task

You can assist an agent whose call you are observing by choosing Talk mode. If you choose Talk, you can talk to the caller and the agent.

Before you begin

Ensure that your administrator configures the Talk feature and you are already observing a call.

Procedure

While on the Call Observation line, press the **Talk** softkey to talk to your agent and the caller.

SLA Mon[™]

SLA Mon[™] technology is a patented Avaya technology embedded in Avaya products to facilitate advanced diagnostics. The phones support SLA Mon[™] agent which works with Avaya Diagnostic Server (ADS).

SLA Mon[™] server controls the SLA Mon[™] agents to execute advanced diagnostic functions, such as:

- Endpoint diagnostics
 - To remotely control IP phones to assist end users with IP phone configuration and troubleshooting.
 - To remotely generate single and bulk test calls between IP phones.
 - To remotely execute limited packet captures on IP phones to troubleshoot and diagnose IP phone network traffic.
- Network monitoring
 - To monitor multiple network segments for performance in terms of packet loss, jitter, and delay.
 - To monitor hop-by-hop QoS markings for voice and video traffic.

Shared control

With the Shared Control feature, you can operate phones from the Avaya Workplace Client client and use high quality audio of the phone. Shared control is supported on all the Avaya J100 Series IP Phones models.

Phones must be registered with Avaya Aura® to establish a shared control connection. When you log in to your phone and Avaya Workplace Client in the shared control mode, you can control the phone through Avaya Workplace Client. A shared control session might not be established if multiple devices are registered to the same user, depending on the client implementation.

The Shared Control feature must be activated by the administrator and configured on Avaya Workplace Client.



Note:

This feature is available only in Avaya Aura® environment.

You can perform the following tasks on the Avaya J100 Series IP Phones:

- · make a call
- · answer a call
- place and resume a call on hold
- · mute and unmute a call
- · call transfer
- · conference

Notifications

You will get the following messages on your ePhone screen after the phone is configured or disconnected from Avaya Workplace Client:

- · Shared Control is active
- · Shared Control is inactive

For information on installing and configuring Avaya Workplace Client, see *Planning for and Administering Avaya Workplace Client for Android, iOS, Mac, and Windows* and *Using Avaya Workplace Client for Android, iOS, Mac, and Windows*.

Team Button

When the administrator configures the Team Button feature for your phone, you can do the following:

- Monitor another phone to know whether calls are redirected to another phone.
- · Monitor another phone to know whether that phone has an active call.
- Answer calls that ring on the monitored phone.

Use the Team Button soft key to:

- Make a speed dial call to the monitored phone. You can do this when the monitored phone is not in use.
- Transfer an active call to the monitored phone.

The call redirection feature, Send All Calls, Call Forward, or ECF might be active on the monitored phone. The monitoring phone can override call redirection when speed dialing or transferring an active call to the monitored phone. The override feature ensures that the call made to the monitored phone rings on the monitored phone and is not routed to the redirected number.

To override call redirection, the administrator must configure on Avaya Aura[®] Session Manager:

- The monitored phone setting that enables the monitoring phone to override call redirection directly or through a choice provided to the user.
- The monitoring phone setting that enables the phone to override the call redirection feature that is active on a monitored phone.

For more information to set the overriding permission on Avaya Aura[®] Session Manager, see *Administering Avaya Aura*[®] *System Manager*.

The following table shows icons of the Team Button feature icons for Avaya J169/J179 IP Phone and Avaya J100 Expansion Module:

Icon	Description
	•

Table continues...

	The monitored extension is idle.
0	The monitored extension is on another call.
0	The monitored extension is idle, but the user has forwarded all incoming calls to a different extension.
0	The monitored extension is on another call, and the user has forwarded all incoming calls to another extension.

The following table shows icons of the Team Button feature for JBM24 Button Module:

Icon	Description
6	The monitored extension is idle.
©	The monitored extension is on another call.
9	The monitored extension is idle, but the user has forwarded all incoming calls to a different extension.
(P)	The monitored extension is on another call, and the user has forwarded all incoming calls to another extension.

Answering an active call on a monitored extension

Procedure

- 1. Press **Main menu**, and scroll to **Features**.
- 2. Press Select.
- 3. Scroll to choose the monitored extension for which you want to answer the incoming call.
- 4. Press Select.

Viewing the status of monitored stations

Procedure

- 1. Press Main menu, and scroll to Features.
- 2. Press Select.
- 3. Scroll to view the status of the required monitored extension.

The Team button screen remains active until you close the screen.

Speed dialing to a monitored extension

About this task

Use this task to make a call to a monitored phone. If the monitored phone has an active call redirection feature and you can override the feature, the monitored phone rings for 30 seconds. If no one answers the call during this time, the system redirects the call to the redirected number.

Before you begin

Ensure that the monitored phone to which you make the call is in an idle state.

Procedure

- 1. Press Main menu, and scroll to Features.
- 2. Press **Select**.
- 3. Scroll to choose the monitored phone that you want to call.
- 4. Press **Select** twice.

The phone makes a call to the monitored extension.

Transferring a call to a monitored phone

About this task

Use this procedure to transfer an active call to a monitored phone.

Before you begin

You must be on an active call.

Procedure

- 1. Press Main menu, and scroll to Features.
- 2. Press Select.
- 3. Scroll to choose the monitored phone to which you want to transfer the active call, and press **Select**.

The system puts the active call on hold and rings the monitored phone.

- 4. To complete the transfer, perform one of the following actions:
 - Press the Complete soft key.
 - On-hook the handset.
 - Press the Speaker button.
 - Press the Now soft key.

• Press the Talk soft key.

Monitoring other extensions at a glance

About this task

Use this procedure to monitor phones for others. You can see whether an extension is idle or busy at a glance.

Before you begin

Ensure that the feature is activated by the administrator. Contact your administrator for details.

Procedure

- 1. Press **Main menu**, and scroll to **Features**.
- 2. Press Select.
- 3. Scroll to the System Numbers.
- 4. If necessary, scroll to the line button for the extension you want to check.
- 5. If that extension is in use, the phone displays **Busy** next to the extension number.

Tracing a malicious call

About this task

Use this feature to trace a malicious call. Activating Malicious Call Trace (MCT Act) alerts a controller to begin call tracing and provide information for reporting this call. This feature is available only if your administrator has set up the phone system to trace and track malicious calls and there is an attendant or controlling user to oversee the trace.

Procedure

- 1. During an active call, access the Features menu.
- 2. To start a trace, scroll to Malicious call trace, and press one of the following:
 - Select
 - Corresponding line button

An alerting tone or flashing LED signifies the trace is active. Hanging up deactivates MCT Act.

Important:

Some countries, states, and localities have laws that determine if and under what circumstances you can use Malicious Call Trace (MCT). Before using the MCT feature, you must understand and comply with these laws.

Using a Guest Login

About this task

Use this procedure to log in as a guest on another phone to access your applications and call history for a limited time.

Note:

You need to re-login if the phone reboots.

Before you begin

Ensure that the feature is activated by the administrator. Contact your administrator for details.

Procedure

- 1. Press Main menu.
- 2. Scroll to Applications, and press Select.
- 3. Scroll to **Guest login**, and press **Select**.
- 4. Enter your extension and password.
- 5. Press one of the following to set the duration in hours:
 - Right arrow key: To increase the value.
 - Left arrow key: To decrease the value.
- 6. Press Enter.

Related links

Logging out of your phone on page 22

WML browser

Wireless Markup Language (WML) is an XML-based markup language used by Avaya J100 Series IP Phones.

The WML browser feature allows you to view WML web pages.

With the WML browser feature, you can access the Home page, Click to Dial and Add to Contacts applications.

All WML browser elements are designed by the system administrator. Contact your system administrator if you want to change the pre-configured layout.

If your system administrator has enabled this option, you can pick up incoming calls with WML browser open, using off-hook or headset button from the WML browser view.

Accessing the WML browser

About this task

You can access pre-configured WML browser applications which are added to your phone in addition to applications in the Settings menu.

Before you begin

Ensure the system administrator has configured the Browser application.

- 1. Press Main menu.
- 2. Scroll to **Applications**, and press **Select**.
- 3. Scroll to **Browser**, and press **Select**.
- 4. Use the following controls to access the Browser application elements:
 - a. **Up** and **Down** navigation arrows to scroll the Home page up or down
 - b. Left and Right navigation arrows to navigate the history
 - c. **OK** button to go to a page link or select an option
 - d. Home to go to the Home page
 - e. Refresh to reload the current card
 - f. **Exit** to return to the Applications menu

Chapter 12: Customization

Phone

Setting the dialing mode

About this task

Use this procedure to set the dialing method used to initiate dialing.

Procedure

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to Phone, and press Select.
- 4. Scroll to Dialing mode.
- 5. Press **Toggle** to select one of the following options:
 - Manual: Press the Call soft key to start a call.
 - Auto: Ensure that the dialed digits match the dial plan to start a call.
 - Default: Press the Call soft key to start a call.
- 6. Press Save.

Related links

Making a call by using the manual dial mode on page 35 Making a call by using the auto-dial mode on page 35 Using URI dialing to make a call on page 83

Displaying call timers

About this task

Use this procedure to display the duration of calls.

Procedure

1. Press Main menu.

- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to **Phone**, and press **Select**.
- 4. Use the **Down Arrow** key to go to the **Display call timers**.
- 5. Press **Toggle** to activate or deactivate the call timers.
- 6. Press Save.

Setting key repeat delay

Before you begin

Ensure that the key repeat delay settings are activated by your administrator.

Procedure

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to Phone, and press Select.
- 4. Scroll to Key repeat delay.
- 5. Press **Toggle** to select one of the following:
 - Default
 - Long
 - Longest
 - Off
 - Short
- 6. Press Save.

Setting redial options

About this task

Use this procedure to see the last dialed numbers.

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to Phone, and press Select.
- 4. Scroll to the **Redial** option.

- 5. Press **Toggle** to one of the following:
 - One number: To call to the last dialed number immediately
 - List: To see a list of the last eight numbers.
 - Default: To call to the last dialed number immediately
- 6. Press Save.

Related links

Redialing a number on page 36

Assigning speed dial entries

About this task

Use this procedure to assign speed dial numbers to your contacts. You can assign up to nine speed dial entries.

This feature is only available in the Avaya Aura® environment.

Procedure

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to Phone, and press Select.
- 4. Scroll to Assign speed dial entries.
- 5. Use the **Up** and **Down Arrow** keys to select a speed dial number.
- 6. Press Contacts to select a contact.
- 7. Press **Select** to assign the contact to the selected speed dial number.

You can assign only one contact.

Related links

Making a call by using speed dial on page 37

Replacing and clearing a Speed Dial contact

About this task

Use this procedure to replace or remove a Speed Dial contact.

Before you begin

Assign a contact to a Speed Dial number.

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.

- 3. Scroll to Phone, and press Select.
- 4. Select Assign speed dial entries.
- 5. Use the **Down Arrow** key to go to the Speed Dial contact that you want to replace or clear.
- 6. Press one of the following:
 - **Replace**: To replace the contact with another contact.
 - Clear: To remove the contact from the Speed Dial.
- 7. Press **Replace** or **Clear** when the phone prompts for confirmation.

Setting Mute alert

About this task

Use this procedure to receive a notification alert when your phone is on mute and you try to answer a call.

Before you begin

Ensure that the feature is activated by the administrator. Contact your administrator for details.

Procedure

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to **Phone**, and press **Select**.
- 4. Scroll to **Mute alerting** option.
- 5. Press **Toggle** to select one of the following:
 - Audible: The phone beeps to notify that you have muted your phone.
 - Visual: The phone displays the mute icon after some time on the phone status line.
 - **Both**: The phone beeps and displays a mute alert message.
 - None: The phone disables the mute alert.
- 6. Press Save.

Visual alerting

The beacon LED works in the following manner to indicate incoming calls and messages:

- If there is an incoming call, the beacon LED blinks.
- If there are new voice mail messages, the beacon LED is lit continuously.
- If the speaker is on during an active call and there are new voice mail messages, the beacon LED turns off every 15 seconds.

Note:

If the call is on hold, the beacon LED stops flashing.

Related links

Setting Visual alerting on page 103

Setting Visual alerting

About this task

Use this procedure to illuminate the beacon LED when there are incoming calls and messages.

Procedure

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to Phone, and press Select.
- 4. Scroll to Alerting on calls, and press Select.
- 5. Scroll to Beacon LED.
- 6. Press **Toggle** to enable or disable visual alerting.
- 7. Press Save.

Related links

Visual alerting on page 102

Customizing phone keys

About this task

Use this procedure to add, relabel, move, or delete contacts, features, or applications from the Phone screen.

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to Phone, and press Select.
- 4. Scroll to Phone keys customization, and press Select.
- 5. Press Customize key.
- 6. Use **Navigation** keys to select the line key.
- 7. **(Optional)** On the phone screen, if the selected line is empty, press **Add**, and do the following:
 - To add a contact, press **Contact**.

- To add a feature, press Feature.
- To add an application, press App.

You can use the Navigation keys to scroll to the required functionality, and press **Select**.

- 8. To move the selected line key, do the following:
 - a. Press Move.
 - b. Use the Navigation keys to move the selected line.
 - c. (Optional) If the new location is empty, press Select.
 - d. **(Optional)** If the new location is already assigned a key, press **Swap**.
- 9. To set a new label, do the following:
 - a. Press Relabel.
 - b. Type the name of the label.
 - c. If your native language uses extended Latin or non-Latin symbols, press **More** > **Symbol** the soft key to open the Symbols menu and select the necessary symbols there. Press **Insert** > **More** > **Save**.
- 10. To delete a key, press **Delete**, and then confirm the deletion.

Restoring customized keys to default

About this task

Use this procedure to restore the customized keys to administrator settings.

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to **Phone**, and press **Select**.
- 4. Scroll to Phone keys customization, and press Select.
- 5. Scroll to **Restore**, and press **Select**.
- 6. In the confirmation window, press **Restore**.

Applications

Enabling the Away timer

Procedure

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to **Applications**, and press **Select**.
- 4. Scroll down to Presence integration, and press Select.
- 5. Scroll down to Away timer.
- 6. Press **Toggle** to turn on the timer.
- 7. Use the **Down Arrow** key to go to **Away timer value**.
- 8. Enter the time in seconds.

You can enter any value from 0 to 999.

9. Press Save.

Enabling phone auto-lock

About this task

You can set your phone to auto-lock when not in use. The idle phone automatically locks itself after the set time period elapses.

Procedure

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to **Applications**, and press **Select**.
- 4. Scroll down to Lock.
- 5. Enter the time in minutes.

You can enter any value from 0 to 999.

If you do not enter any value, the phone uses the administrator set value.

6. Press Save.

Turning call history on and off

Procedure

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to **Applications**, and press **Select**.
- 4. Scroll to Recents, and press Select.
- 5. Scroll to **Log calls**, and press one of the following:
 - Toggle: To toggle call history on or off.
 - Right Arrow key: To turn on call history.
 - Left Arrow key: To turn off call history.
- 6. Press Save.

Microsoft® Exchange account integration

You can integrate your phone with the Microsoft[®] Exchange account by using the Microsoft[®] authentication method. Your system administrator can integrate your phone with the Exchange account from the back-end or provide you the access to enter your Microsoft[®] Exchange credentials on your phone. After successful authentication, your Exchange calendar and Contacts are integrated with your phone.

Entering Microsoft® Exchange credentials for basic authentication

About this task

You can integrate your phone with Microsoft[®] Exchange account by using the Basic authentication method. Your system administrator provides you access to enter your Microsoft[®] Exchange credentials on your phone. Depending on the settings made by your administrator, the phone screen displays the options to enter the details.

Before you begin

Ensure that you have a valid exchange credential.

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to **Applications**, and press **Select**.
- 4. Scroll to Exchange credentials, and press Select.

- 5. (Optional) Press Toggle to select the required authentication method.
- 6. Do the following for the **Basic** authentication method:
 - Enter Exchange username.
 - Enter Exchange password.
 - · Enter Exchange domain.
 - Press Toggle to select the Name/Password Prompt.

If you select **Name/Password Prompt**, the phone prompts for username and password every time you access the Calendar application.

7. Press Save.

Result

Basic authentication is successful, and your phone is integrated with the Microsoft® Exchange account.

Entering Microsoft® Exchange credentials for OAuth authentication

About this task

You can integrate your phone with Microsoft® Exchange account by using the OAuth authentication method. Your system administrator provides you access to enter your Microsoft® Exchange credentials on the phone. Depending on the settings made by your administrator, the phone screen displays the options to enter the details.

Before you begin

Ensure your that you have a valid exchange credential.

Procedure

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to **Applications**, and press **Select**.
- 4. Scroll to Exchange credentials, and press Select
- 5. (Optional) Press Toggle to select the required authentication method.
- 6. Enter the following for the **OAuth** authentication method:
 - Email address
 - Sever address
- 7. Press Save.

The **Save** soft key appears only after you enter the valid details.

- 8. The phone screen displays the device verification URL https://microsoft.com/devicelogin and the dynamically generated User code for verification.
 - The phone screen displays these details for a maximum of 15 minutes.
- 9. Enter the URL in your computer browser and enter the User code when the Microsoft® application prompts.
- 10. Follow the user prompts of the Microsoft® application.

Result

OAuth authentication is successful, and your phone is integrated with the Microsoft® Exchange account.

Enabling and disabling Microsoft® Exchange contact integration Procedure

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to **Applications**, and press **Select**.
- 4. Scroll to Contacts, and press Select.
- 5. Scroll to **Enable exchange contacts**, and press one of the following:
 - Toggle: To enable or disable Exchange contacts.
 - Right Arrow key: To enable Exchange contacts.
 - Left Arrow key: To disable Exchange contacts.
- 6. Press Save.

Calendar settings

Enabling and disabling Exchange calendar

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to **Applications**, and press **Select**.
- 4. Scroll to Calendar, and press Select.
- 5. Scroll to **Enable Exchange Calendar**, and press one of the following:
 - Toggle: To enable or disable Exchange calendar.
 - Right Arrow key: To enable Exchange calendar.

- Left Arrow key: To disable Exchange calendar.
- 6. Press Save.

Related links

Enabling and Disabling Calendar reminder on page 109
Reviewing your Calendar event on page 66

Enabling and Disabling Calendar reminder Procedure

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to **Applications**, and press **Select**.
- 4. Scroll to Calendar, and press Select.
- 5. Scroll to **Enable Reminder**, and press one of the following:
 - Toggle: To enable or disable calendar reminder.
 - Right Arrow key: To enable calendar reminder.
 - Left Arrow key: To disable calendar reminder.
- 6. Press Save.

Related links

Enabling and disabling Exchange calendar on page 108
Reviewing your Calendar event on page 66

Enabling and Disabling Calendar reminder tone Procedure

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to **Applications**, and press **Select**.
- 4. Scroll to Calendar, and press Select.
- 5. Scroll to **Reminder Tone**, and press one of the following:
 - **Toggle**: To enable or disable the reminder tone.
 - **Right Arrow** key: To enable the reminder tone.
 - **Left Arrow** key: To disable the reminder tone.
- 6. Press Save.

Setting a reminder and snooze time

Procedure

- 1. Press Main menu.
- 2. Scroll to Settings, and press Select.
- 3. Scroll to **Applications**, and press **Select**.
- 4. Scroll to Calendar, and press Select.
- 5. Scroll to **Reminder Time**, and enter the number of minutes. The range is 0 to 99.
- 6. Scroll to **Snooze Time**, and enter the number of minutes. The range is 0 to 99.
- 7. Press Save.

Setting a day of the week for calendar reminder

Procedure

- 1. Press Main menu.
- 2. Scroll to Settings, and press Select.
- 3. Scroll to **Applications**, and press **Select**.
- 4. Scroll to Calendar, and press Select.
- 5. Scroll to First Day of Week.
- 6. Press one of the following:
 - Toggle: To change the day.
 - Right Arrow key: To change the day in ascending order.
 - Left Arrow key: To change the day in descending order.
- 7. Press Save.

Setting Calendar list

- 1. Press Main menu.
- Scroll to Settings, and press Select.
- 3. Scroll to **Applications**, and press **Select**.
- 4. Scroll to Calendar, and press Select.
- 5. Scroll down to **List Style**, and press one of the following:
 - Expanded
 - Compact
- 6. Press one of the following:
 - Toggle

- Right Arrow key
- Left Arrow key
- 7. Press Save.

Activating Do not disturb

About this task

Use this procedure to direct incoming calls to a predefined coverage number that is set by the system administrator.

In the IP Office environment, this feature is supported using short code dialing. Contact your system administrator for the list of short codes.

Before you begin

Your system administrator must activate the feature for your extension.

Procedure

- 1. Press Main menu > Features.
- 2. Use the **Down Arrow** key to go to the Do not disturb screen.
- 3. Select Do not disturb.

Redirecting calls when Do Not Disturb is active

About this task

When your Presence status is set to **Do Not Disturb**, use this procedure to redirect calls.

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to **Applications**, and press **Select**.
- 4. Scroll to **Presence integration**, and press **Select**.
- 5. Scroll to **DND invokes SAC**.
- 6. Press **Toggle**, and set the value to **Yes**.
- 7. Press Save.

Audio

Turning automatic gain control on or off

About this task

Use this procedure to adjust the audio output level to for better quality audio.

Procedure

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to Audio settings, and press Select.
- 4. Scroll to Automatic gain control, and press Select.
- 5. Select the handset, headset, or speaker for which you want to turn automatic gain control on or off.
- 6. Press **Toggle** to turn automatic gain control on or off.
- 7. Press Save.

Enabling and disabling Bluetooth

About this task

You can use Bluetooth enabled devices with your phone.



Avaya J169 IP Phone does not support the Bluetooth feature.

Before you begin

• Ensure the wireless module is installed in your phone.

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll down to **Bluetooth**, and press **Select**.
- 4. Scroll to **Bluetooth headset**, and press one of the following:
 - Toggle: To enable or disable Bluetooth.
 - Right Arrow key: To enable Bluetooth.
 - Left Arrow key: To disable Bluetooth.

Note:

For some Bluetooth headsets, volume can be adjusted during the first call after rebooting the phone. Toggle the slider of the pop-up panel to the right to increase the volume, and to the left to decrease it.

Pairing a Bluetooth enabled headset with your phone

About this task

You can pair a maximum of ten Bluetooth enabled headsets with the phone, but you can use only one headset at a time. The phone displays the list of available devices and paired devices.

Before you begin

- Ensure the wireless module is installed in your phone.
- Ensure that the feature is activated by the administrator. Contact your administrator for details.
- Ensure your Bluetooth headset is in pairing mode.

Procedure

- 1. Press Main menu.
- Scroll to Settings, and press Select.
- 3. Scroll down to **Bluetooth**, and press **Select**.
- 4. Scroll to **Devices**, and press **Select**.

The phone scans and displays the list of Bluetooth enabled devices.

- 5. To pair a device, scroll to the headset, and press **Pair**.
- 6. To disconnect a paired headset, under Paired devices, press **Disconct**.
- 7. To unpair a paired headset, under Paired devices, press **Forget**.

Related links

Pairing wireless BT headset (Video)

Turning button clicks on and off

- 1. Press Main menu.
- Scroll to Settings, and press Select.
- 3. Scroll to **Audio** settings, and press **Select**.
- 4. Use the **Down Arrow** key to go to the Button clicks screen.
- 5. Press **Toggle** to turn the audio on or off.

6. Press Save.

Turning error tones on and off

About this task

Use this procedure to activate the error tone alarm when you perform an incorrect action while using the phone.

Procedure

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to Audio settings, and press Select.
- 4. Use the **Down Arrow** key to go to the Error tones screen.
- 5. Press **Toggle** to turn error tones on or off.
- 6. Press Save.

Enabling wireless headset bidirectional signaling

Before you begin

Check if the headset supports electronic hook switch (EHS) signaling.



Headset Signaling setting is used to configure only DECT headsets and cannot be applied to Bluetooth headsets.

- 1. Press Main menu.
- Scroll to Settings, and press Select.
- 3. Scroll to Audio settings, and press Select.
- 4. Scroll to Headset signaling.
- 5. Press **Toggle** to select one of the following options:
 - **Disabled**: Disables signaling from the phone to the headset.
 - **Switch hook and alert**: Activates the link to the headset if you press **Headset**. When the phone receives an incoming call, you hear the alert tone in the headset.
 - **Switch hook only**: Activates the link to the headset if you press **Headset**. When the phone receives an incoming call, you do not hear the alert tone in the headset.
- 6. Press Save.

Setting headset mic level

About this task

Use this procedure to adjust the best headset performance.

Before you begin

- Ensure that you are on a call and the caller's audio level is at 50%.
- Adjust the microphone position as recommended by your headset vendor.

Procedure

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to **Audio** settings, and press **Select**.
- 4. Scroll to **Headset mic level**, and press **Select**.
- 5. Press one of the following:
 - Right arrow key: To increase the gain level.
 - Left arrow key: To decrease the gain level.
- 6. (Optional) To set the default gain level, press Default.

Configuring hearing aid compatibility

Procedure

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- Scroll to Audio settings, and press Select.
- 4. Scroll to **Handset profile**, and press **Select**.
- 5. Press one of the following:
 - Default
 - Normal
 - **Amplified**: Magnifies the normal audio level. The option must be used with caution because long term extended use of the highest volume settings can cause ear damage.
 - Note:

The amplified audio level will return to normal when the call is ended.

- Hearing Aid: Optimizes the sound quality of hearing aids.
- 6. Press Save.

Setting a headset profile

About this task

Use the procedure to select the headset profile that best matches the acoustic properties of the headset.

Note:

Headset profiles 6, 7, and 8 are designed to work only with wireless headsets.

Procedure

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to **Audio** settings, and press **Select**.
- 4. Scroll to **Headset profile**, and press **Select**.
- 5. Scroll to the profile that matches your headset.
- 6. Press Select.
- 7. Press Save.

Related links

List of headset profiles on page 116

List of headset profiles

Headset Profile	Description	
Profile 1	L100 Series Headsets	
Profile 2	Plantronics: SupraPlus [®] Wideband HW251N/HW261N (HIS)	
	• Sennheiser: SH 330/SH 350, CC 510/CC 550 (CAVA-31)	
Profile 3	Plantronics: EncorePro® HW291N/HW301N (HIS)	
	• Sennheiser: Circle™ SC 230/260 (CAVA-31)	
Profile 4	• Jabra: BIZ [™] 2400 (GN1216)	
	• Sennheiser: Century [™] SC 630/660 (CAVA-31)	
	• VXI: CC Pro [™] 4010V DC, CC Pro [™] 4021V DC (OmniCord-V)	
Profile 5	Jabra: GN2000 (GN1216)	
Profile 6	Jabra: PRO [™] 9470 (14201-33)	
Profile 7	Plantronics:	
	• CS500 [™] Series: CS510, CS520, CS530, CS540 (APV-63)	
	• Savi [®] 700 Series: W710, W720, W730, W740, W745 (APV-63)	

Table continues...

Headset Profile	Description	
Profile 8	Sennheiser:	
	DW Pro1/DW Pro2 SD Pro1/SD Pro2 (CEHS-AV03/AV04)	
	DW Office, SD Office (CEHS-AV03/AV04)	

Related links

Setting a headset profile on page 116

Setting a personalized ringtone

About this task

Use this procedure to set a ringtone for different uses.

Procedure

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to **Audio** settings, and press **Select**.
- 4. Scroll to Personalize ringing, and press Select.
- 5. Scroll to one of the following options:
 - Primary
 - Team Key
 - Bridged CA
 - Call Pickup
- 6. Press Select.
- 7. Scroll to the ringtone, and press **Select**.
- 8. (Optional) To play the ringtone, press Play.
- 9. Press Save.

Display

Changing the background image

Procedure

1. Press Main menu.

- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to **Display**, and press **Select**.
- 4. Scroll to **Background**, and press **Select**.
- 5. Scroll to Primary display, and press Select.
- 6. Scroll down to the new image.
- 7. **(Optional)** To preview the image, press **Preview** and then press **Back**.
- 8. Press Select.
- 9. Press Save.

Changing the screen saver

Procedure

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to Display, and press Select.
- 4. Scroll to Screen saver and press Select.
- 5. Scroll to Primary display, and press Select.
- 6. Scroll down to the new image.
- 7. To preview the image, press **Preview** and then **Back**.
- 8. Press Select.
- 9. Press Save.

Setting the screen saver details

About this task

Use this procedure to change the time that elapses before the phone displays a screen saver and to enable clock display on the screen saver.

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to Display, and press Select.
- 4. Scroll to Screen saver details, and press Select.
- 5. To change the screen saver time, scroll down to **Timer (min)**, and enter time in minutes.

You can enter any value from 0 to 999.

- 6. To enable clock on the screen saver, scroll to **Clock**, and press **Toggle**.
- 7. Press Save.

Adjusting the brightness of a phone screen

Procedure

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to Display, and press Select.
- 4. Scroll to **Brightness**, and press **Select**.
- 5. Scroll to one of the phone display and press **Select**:
 - Primary display
 - Name of the button module attached to the phone.
- 6. On **Phone**, press one of the following:
 - Right Arrow key: To increase the brightness.
 - Left Arrow key: To decrease the brightness.

Setting the display language

Procedure

- 1. Press Main menu.
- 2. Scroll to Settings, and press Select.
- 3. Scroll to **Display**, and press **Select**.
- 4. Scroll to Language, and press Select.
- 5. Scroll to the language, and press **Select**.
- 6. Press one of the following when the phone prompts for confirmation:
 - Confirm
 - Cancel

The phone returns to the Display screen and the language changes to the selected language.

Setting the backlight timer

Procedure

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to **Display**, and press **Select**.
- 4. Scroll to **Backlight timer**, and enter the number of minutes. The range is 0 to 999.
- 5. Press Save.

Setting the time format

Before you begin

Ensure that your administrator has enabled the time format feature.

Procedure

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to **Display**, and press **Select**.
- 4. Use the **Down Arrow** key to go to the Time format screen.
- 5. Press **Toggle** to select one of the following options:
 - Time format 24 Hour
 - Time format 12 Hour
- 6. Press Save.

Setting the date format

Procedure

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to **Display**, and press **Select**.
- 4. Use the **Down Arrow** key to go to the Date format screen.

The phone displays one of the following:

- Default
- · mm/dd

- · dd/mm
- mm.dd
- · dd.mm
- · mm-dd
- dd-mm
- · mmm dd
- 5. Press **Toggle** to select one of the options.
- 6. Press Save.

Setting the time zone

About this task

Use this procedure to set the current time of the phone.

Procedure

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to Display, and press Select.
- 4. Scroll to **Time zone**, and press **Select**.

The phone displays the following:

- My time
- Time zone
- 5. To set the required time, do one of the following:
 - Use the Left Arrow and Right Arrow key.
 - Press or + soft key.
- 6. Press Save.

Setting the text size

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to **Display**, and press **Select**.
- 4. Scroll down to **Text size**, and press **Select**.

- 5. Scroll down to **Primary display**, and press **Select**.
- 6. Press one of the following:
 - Right arrow key: To increase the font size.
 - Left arrow key: To decrease the font size.
- 7. (Optional) Press Default to restore the default font size.
- 8. Press Save.

Setting the phone screen width

Procedure

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to **Display**, and press **Select**.
- 4. Scroll to Phone screen width, and press Select.
- 5. Press **Toggle** to select one of the following options:
 - Full: Each call appearance or feature occupies the entire width of a line.
 - Half: Each call appearance or feature occupies half the width of a line, effectively splitting the screen in two halves.
 - Default: Each call appearance or feature occupies the entire width of a line.
- Press Save.

Setting the network mode

About this task

You can set the network mode to **Ethernet** or **Wi-Fi**. You do not need to perform this procedure if your phone is configured to connect to Ethernet or a specific Wi-Fi network.

Avaya J169 IP Phone does not support the Wi-Fi feature.

Before you begin

Ensure that the system administrator gave you access to perform this task.

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to **Network**, and press **Select**.

4. Scroll to Network mode.

The **Network mode** setting shows the following options:

- Ethernet: To connect to an Ethernet network.
- Wi-Fi: To connect phone to a Wi-Fi network.
- 5. Press one of the following:
 - Toggle
 - Right arrow key
 - Left arrow key
- 6. When **Network mode** displays **Wi-Fi**, the following lines are shown on the Phone screen:
 - **SSID**: The name of the Wi-Fi network that the phone is either currently connected to, or will attempt to connect to if you start the connection process.
 - Wi-Fi network: Scroll to this line and press Select to view the list of Wi-Fi networks.
- 7. After selecting the network mode, press **Save**.
- 8. When you switch **Network mode** from **Ethernet** to **Wi-Fi**, see "Connecting to a Wi-Fi network" section.
- 9. When you switch **Network mode** from **Wi-Fi** to **Ethernet**, press **Save**.
- 10. When the phone prompts for permission to restart, press **OK**.

Press Cancel to go back to previous step.

Related links

<u>Setting the network configuration</u> on page 123 Connecting to a Wi-Fi network on page 124

Setting the network configuration

About this task

To set the network configuration to Auto or Manual. You do not need to perform this procedure if your phone is configured to connect to Ethernet or a specific Wi-Fi network.

When network configuration is Auto, every time the phone restarts, it will connect to the preconfigured network that your administrator has set up.

When network configuration is Manual, every time the phone restarts, it will connect to the network that you manually configured by <u>Setting the network mode</u> on page 122 or <u>Connecting to a Wi-Fi network</u> on page 124, irrespective of the pre-configured network that your administrator has set up.



Any time you manually change the connected network, the phone will automatically set **Network config** to **Manual**.

Procedure

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to **Network**, and press **Select**.
- 4. Scroll to Network config.

The Network configuration shows following two options:

- Auto: To automatically connect a network.
- Manual: To manually connect to a network.
- 5. Press one of the following:
 - Toggle
 - · Right arrow key
 - Left arrow key
- 6. Press one of the following:
 - Save
 - OK
 - Note:

If you do not want your phone to restart and stay in the Manual mode when you switch **Network config** from **Auto** to **Manual**, press **Save**.

If you switch **Network config** from **Manual** to **Auto**, press **Save** and then do either of the following:

- If the currently-connected network is the same as the pre-configured network that your administrator has set up, the phone will not restart and stay in the Auto mode.
- If the currently-connected network is not the same as the pre-configured network that your administrator has set up, the phone will prompt you for permission to restart before connecting to the pre-configured network.

Related links

Setting the network mode on page 122

Connecting to a Wi-Fi network

About this task

Use this procedure if your phone is not configured to connect to a specific Wi-Fi network Avaya J169 IP Phone does not support the Wi-Fi feature.

Before you begin

- Ensure that the system administrator gave you access to perform this task.
- Select Wi-Fi as your network mode.
- When you set the network mode, note the SSID, as this is the name of the Wi-Fi network that the phone will attempt to connect to.
- Depending on the type of security in the Wi-Fi network, obtain the required credentials. Contact your system administrator for more details.

Procedure

- 1. Press Main menu.
- 2. Scroll to **Settings**, and press **Select**.
- 3. Scroll to Network, and press Select.
- 4. To access the list of available Wi-Fi networks, scroll to Wi-Fi network, and press Select.
- 5. Scroll to the required **Wi-Fi network**, and press **Connect** to start the connection process.
- 6. Press **OK** to restart the phone.
- 7. If the security is WEP or WPA/WPA2 PSK, in **Password**, enter the password for the Wi-Fi network.
- 8. If the security is 802.1x EAP, enter the following:
 - **Identity**: Either your personal user ID or the shared user ID provided by your system administrator.
 - **Anonymous Identity**: Leave blank or use the shared Anonymous Identity provided by your system administrator.
 - **Password**: Either your personal password or the shared password provided by your system administrator.

Result

If the credentials are authenticated successfully, the phone automatically restarts to complete the connection.

Related links

Setting the network mode on page 122

Chapter 13: Troubleshooting

Limited access during failover

One or more telephone system servers provide your phone with its connectivity, features, and functionality. If a disconnect or switch from one server to another occurs, your phone goes into Failover mode to keep it operating while alternate server resources are established. Depending on the server your phone is on, an icon may appear on the Top display line to notify you that failover is in effect.

Failover has different stages. For example, while your phone transitions to a new server it is in "limbo" and functionality may be limited. When the alternate server is active, your phone assumes the functionality available on that server, which may not be the same as your original server. When the original server is restored, your phone transitions back (failback) and functionality may again be limited during the transition. When your phone is back on the original server, normal functionality is restored. Failover and failback are automatic; you have no control over failure mode.

Keep in mind that during failover certain features may not be available and telephone functionality may be limited. Check the soft keys at the bottom of the display to determine the actions you can take during failover. You can also press the **Phone** button to display the for possible actions.

Important:

Do not log your telephone off during failover or until normal service is restored on your original telephone server. Logging off during failover, during transition to or from an alternate server, or while your phone is active on an alternate server may cause your phone to become inoperable.

The following conditions apply when your telephone is in Failover mode:

- If you are on a call when failover occurs, the call will remain active. You cannot initiate new calls while your phone transitions to the alternate server.
- Certain soft keys may not display and their related functions may be unavailable until transition to the alternate server is complete.
- Call connection may take longer than usual.
- During the transition to a new server, any active conference calls, call transfers, and held calls may be dropped. Incoming calls might not reach you and can go to voice mail.
- Emergency calls might or might not work, depending on the stage of failover and the functionality available on the alternate server.

- The Message Waiting Indicator is cleared, but voice mail might still be available if the voice mail server to which calls are being sent is not in failover.
- Transitions back to the normal server will restore all original functionality.

Recording audio parameters

About this task

Use this procedure to record audio parameters information in your phone.



Note:

The saved audio parameters information is used for audio debugging.

Procedure

- 1. Press Main menu.
- 2. Scroll to **Network information**, and press **Select**.
- 3. Scroll to Audio parameters, and press Select.
- 4. Press the **Record** soft key.
- 5. To stop the recording, press the **Stop** soft key.

Viewing the Product ID

About this task

The product ID information is available on a label on the back panel of your phone. Alternatively, you can view the Product ID on the phone screen.

- 1. Press Main menu.
- 2. Scroll to **Network information**, and press **Select**.
- 3. Scroll to **System**, and press **Select**.
- 4. Scroll to **Product ID**.

Viewing the Device type

About this task

View your device type when your system administrator asks you to provide your device type information. The device type can be either Avaya SIP or Open SIP.

Procedure

- 1. Press Main menu.
- 2. Scroll to **Network information**, and press **Select**.
- 3. Scroll to **System**, and press **Select**.
- 4. Scroll to **Device type**.

Viewing the Server type

About this task

View your server type when your system administrator asks you to provide your server type information. The server type can be of Avaya Aura® or an open SIP.

- 1. Press Main menu.
- 2. Scroll to **Network information**, and press **Select**.
- 3. Scroll to **System**, and press **Select**.
- 4. Scroll to Server type.

Chapter 14: Resources

Documentation

See the following related documents at http://support.avaya.com.

Title	Use this document to:	Audience	
Overview			
Avaya Aura® Session Manager Overview and Specification	See characteristics and capabilities, including feature descriptions, interoperability, performance specifications, security and licensing requirements of the Avaya Aura® Session Manager.	For people who want to gain a high-level understanding of the Avaya Aura® Session Manager features, functions, capacities, and limitations.	
Avaya IP Office [™] Platform Feature Description	See information about the feature descriptions.	For people who perform system administration tasks.	
Avaya IP Office [™] Platform Solution Description	See information about how the products and services interoperate with this solution.	For people who want to gain a high-level understanding of the IP Office features, functions, capacities, and limitations.	
Implementing			
Deploying Avaya Aura® Session Manager	See the installation procedures and initial administration information for Avaya Aura [®] Session Manager.	For people who install, configure, and verify Avaya Aura® Session Manager on Avaya Aura® System Platform.	
Upgrading Avaya Aura [®] Session Manager	See upgrading checklists and procedures.	For people who perform upgrades of Avaya Aura® Session Manager.	

Table continues...

Title	Use this document to:	Audience
Deploying Avaya Aura® System Manager on System Platform	See the installation procedures and initial administration information for Avaya Aura® System Manager.	For people who install, configure, and verify Avaya Aura® System Manager on Avaya Aura® System Platform at a customer site.
Avaya IP Office™ Platform SIP Telephone Installation Notes	See the installation procedures and initial administration information for IP Office SIP telephone devices.	For people who install, configure and verify SIP telephone devices on IP Office.
Administering		
Administering Avaya Aura® Session Manager	See information about how to perform Avaya Aura® Session Manager administration tasks including how to use management tools, how to manage data and security, and how to perform periodic maintenance tasks.	For people who perform Avaya Aura [®] Session Manager system administration tasks.
Administering Avaya Aura® System Manager	See information about how to perform Avaya Aura® System Manager administration tasks including how to use management tools, how to manage data and security, and how to perform periodic maintenance tasks.	For people who perform Avaya Aura® System Manager administration tasks.
Administering Avaya IP Office™ Platform with Manager	See information about short code configurations for the feature list	For people who need to access IP Office features using short codes.
Administering Avaya IP Office™ Platform with Web Manager	See information about IP Office Web Manager administration tasks including how to use the management tool, how to manage data and security, and how to perform maintenance tasks.	For people who perform IP Office Web Manager administration tasks.
Maintaining		
Maintaining Avaya Aura® Session Manager	See information about the maintenance tasks for Avaya Aura® Session Manager.	For people who maintain Avaya Aura [®] Session Manager.
Troubleshooting Avaya Aura® Session Manager	See information for troubleshooting Avaya Aura® Session Manager, resolving alarms, replacing hardware, and alarm codes and event ID descriptions.	For people who troubleshoot Avaya Aura [®] Session Manager.
Using Avaya IP Office™ Platform System Status Application	See information about the maintenance tasks for System Status Application.	For people who maintain System Status Application.

Table continues...

Title	Use this document to:	Audience
Using Avaya IP Office [™] Platform System Monitor	See information about the maintenance tasks for SysMonitor.	For people who maintain SysMonitor.

Finding documents on the Avaya Support website

Procedure

- 1. Go to https://support.avaya.com.
- 2. At the top of the screen, type your username and password and click Login.
- 3. Click Support by Product > Documents.
- 4. In **Enter your Product Here**, type the product name and then select the product from the list.
- 5. In **Choose Release**, select the appropriate release number.

The **Choose Release** field is not available if there is only one release for the product.

6. In the **Content Type** filter, click a document type, or click **Select All** to see a list of all available documents.

For example, for user guides, click **User Guides** in the **Content Type** filter. The list only displays the documents for the selected category.

7. Click Enter.

Avaya Documentation Center navigation

The latest customer documentation for some programs is now available on the Avaya Documentation Center website at https://documentation.avaya.com.

Important:

For documents that are not available on Avaya Documentation Center, click **More Sites** > **Support** on the top menu to open https://support.avaya.com.

Using the Avaya Documentation Center, you can:

- Search for content by doing one of the following:
 - Click **Filters** to select a product and then type key words in **Search**.
 - From **Products & Solutions**, select a solution category and product, and then select the appropriate document from the list.
- Sort documents on the search results page.
- Publish a PDF of the current section in a document, the section and its subsections, or the entire document.

• Add content to your collection by using My Docs (☆).

Navigate to the **Manage Content > My Docs** menu, and do any of the following:

- Create, rename, and delete a collection.
- Add topics from various documents to a collection.
- Save a PDF of selected content in a collection and download it to your computer.
- Share content in a collection with others through email.
- Receive collection that others have shared with you.
- Add yourself as a watcher using the **Watch** icon (<a>).

Navigate to the Manage Content > Watchlist menu, and do the following:

- Enable **Include in email notification** to receive email alerts.
- Unwatch selected content, all content in a document, or all content on the Watch list page.

As a watcher, you are notified when content is updated or deleted from a document, or the document is removed from the website.

- Share a section on social media platforms, such as Facebook, LinkedIn, and Twitter.
- Send feedback on a section and rate the content.

Note:

Some functionality is only available when you log on to the website. The available functionality depends on the role with which you are logged in.

Viewing Avaya Mentor videos

Avaya Mentor videos provide technical content on how to install, configure, and troubleshoot Avaya products.

About this task

Videos are available on the Avaya Support website, listed under the video document type, and on the Avaya-run channel on YouTube.

- To find videos on the Avaya Support website, go to https://support.avaya.com/ and do one of the following:
 - In Search, type Avaya Mentor Videos, click Clear All and select Video in the Content Type.
 - In **Search**, type the product name. On the Search Results page, click **Clear All** and select **Video** in the **Content Type**.

The **Video** content type is displayed only when videos are available for that product.

In the right pane, the page displays a list of available videos.

- To find the Avaya Mentor videos on YouTube, go to www.youtube.com/AvayaMentor and do one of the following:
 - Enter a key word or key words in the **Search Channel** to search for a specific product or topic.
 - Scroll down Playlists, and click a topic name to see the list of videos available for the topic. For example, Contact Centers.

Note:

Videos are not available for all products.

Support

Go to the Avaya Support website at https://support.avaya.com for the most up-to-date documentation, product notices, and knowledge articles. You can also search for release notes, downloads, and resolutions to issues. Use the online service request system to create a service request. Chat with live agents to get answers to questions, or request an agent to connect you to a support team if an issue requires additional expertise.

Index

access limited during failover activating LNCC, limiting incoming calls Active call shortcut keys adding a user. conference call garding a user. overview 55 adding contacts contacts from the Recents list contacts from the Recents list contacts from the Recents list contacts file server address provisioning server answering a call another call pickup group provisioning server answering a call for a pickup group member access calendar activating the screen saver configuring calendar reminder one disabiling calendar reminder tone considers disabiling schange calendar reminder tone considers disabiling schange calendar reminder considers enabling schange calendar reminder enabling calendar reminder tone enabling contact exchange enabling schange calendar reminder tone setting a week day for calendar reminder setting a week day for calendar reminder setting a agent on an observed call setting a person ASC ACC put the contact setting activation of the contact list to the contact list in the cont	A		Avaya support website	<u>133</u>
Active call shortcut keys			away timer	
Active call shortcut keys	access limited during failover	<u>126</u>	timer value	<u>105</u>
Active call shortcut keys adding a user	activating			
Active call shortcut keys adding a user	LNCC, limiting incoming calls	<u>80</u>	R	
Source S	Active call shortcut keys		В	
State	adding a user	<u>57</u>	blind transfer	75
making a call transfer	conference call	<u>57</u>		
adding contacts contacts from the Recents list contacts from the Recents list contacts from the Recents list december contacts december contacts december	making a call transfer	<u>57</u>		113
adding contacts contacts from the Recents list	overview	<u>56</u>		
contacts 41	adding		•	
contacts from the Recents list				61
new call log entry to the Contacts ist 42 number to contacts 42 administrative methods 42 file server address 20 provisioning server 20 answering a call 20 answering a call 20 answering a call for a pickup group 72 73 when on another call pickup group member 72 73 when on another call pickup group member 72 73 when on another call in another call pickup group member 72 73 when on another call on a monitored extension 94 billed transfer 63 icons and LED indication 62 making a coll transfer 63 icons and LED indication 62 making a conference call 63 making a coll transfer 64 billed transfer 65 making a coll frence call in ansfer 65 making a coll transfer 65 making a coll frence call in ansfer 65 making a coll frence call in a coll in ansfer 65 making a coll frence call in ansf	contacts from the Recents list	<u>42</u>		
Autodaling Aut	new call log entry to the Contacts list	<u>42</u>		
administrative methods file server address	number to contacts	<u>42</u>		
File server address	administrative methods		5 5	<u>7 0</u>
answering a call another call pickup group 72, 73 billind transfer 52 billind transfer 53 billind transfer 53 billind transfer 54 billind transfer 55 billind transfer 56 cons and LED indication 56 constance 56 cons and LED indication 56	file server address	<u>20</u>		
answering a call another call pickup group 72, 73 when on another call 32 when on another call 32 answering a call for a pickup group member 72 answering a call for a pickup group member 72 answering a call for a pickup group member 72 answering a call for a pickup group member 72 answering a call for a pickup group member 72 answering a call forward LED indication 52 answering a call forward button clicks 32 making a conference call 32 making a conference call 33 overview 34 applications access calendar 45 call forward button clicks 34 turn off 113 turn on 114 turn on 115 turn on 116 turn on 117 turn on 117 turn on 118 turn on 117 turn on 118 turn on 119 turn on 119 turn on 119 turn on 110 tu	provisioning server	<u>20</u>		64
another call pickup group	answering a call			
Make on another call 32		. 72, 73		
answering a call for a pickup group member 72 making a conference call 52 answering call on a monitored extension 94 applications access calendar 55 access calendar 55 configuring calendar 56 configuring calendar 65 configuring calendar 65 configuring calendar 65 configuration 56 configuration 57 configuration 57 configuration 58 configuration 59 configuration				
answering call on a monitored extension 94 applications 3 applications 3 access calendar 64 activating the screen saver 58 acconfiguring calendar 65 guest login 97 application settings disabling calendar reminder 109 disabling calendar reminder tone 109 enabling calendar reminder 109 enabling calendar reminder tone 109 enabling contact exchange 108 enabling exchange calendar 108 enabling exchange calendar 108 enabling sexchange calendar 101 setting a week day for calendar reminder 110 setting reminder time 110 setting reminder time 110 setting reminder time 110 setting a magent on an observed call 91 audio settings AGC 112 button clicks 113 configuring hearing aid compatibility 115 error tones 114 headset profile setting a primary ringtone 115 setting headset mic level 116 setting a primary ringtone 1				
applications				
access calendar activating the screen saver configuring calendar guest login application settings disabling calendar reminder condisabling calendar reminder tone disabling calendar reminder condisabling calendar reminder disabling calendar reminder condisabling calendar reminder enabling calendar reminder tone enabling calendar reminder tone enabling calendar reminder tone enabling calendar reminder tone enabling exchange calendar enabling SAC when DND is active setting a week day for calendar reminder setting a week day for calendar reminder Assisting an agent on an observed call setting a week day for calendar reminder ASSISSING an agent on an observed call call setting a week day for calendar reminder setting a magent on an observed call setting a magent on an observed call setting a person AGC button clicks call recents URI dialing a person call forward on an oaswer call forward busy call forward busy call forward busy call forward no answer calendar turn on 113 turn on 114 turn on 115 turn on 115 turn on 115 turn on 116 turn on 117 turn on 113 turn on 114 turn on 115 turn on 115 turn on 115 turn on 116 turn on 117 turn on 113 turn on 113 turn on 114 turn on 115 turn on 115 turn on 115 turn on 116 calendar				
activating the screen saver		64		<u>03</u>
C C C C C C C C C C				440
guest login application settings disabling calendar reminder tone disabling calendar reminder tone disabling contact exchange disabling contact exchange disabling calendar reminder tone disabling contact exchange denabling contact exchange denabling exchange calendar disabling calendar reminder disabling calendar event disabling calendar event reminder time disabling calendar event disabling calendar eminder disabling calendar reminder disabling calendar r				
Application settings disabling calendar reminder 109 disabling calendar reminder tone 109 disabling contact exchange 108 enabling calendar reminder 109 enabling calendar reminder tone 109 enabling contact exchange 108 enabling contact exchange 108 enabling sexhange calendar 108 enabling exchange calendar 108 enabling exchange calendar 108 enabling SAC when DND is active 111 setting a week day for calendar reminder 110 setting reminder time 110 setting a magnet on an observed call audio settings AGC 112 button clicks 113 configuring hearing aid compatibility 115 error tones 114 headset profile setting a primary ringtone 115 setting headset mic level 115 setting a person 59 call forward no answer 66 67 call forward no answer 66 call forwa			turn on	<u>113</u>
disabling calendar reminder tone disabling contact exchange enabling calendar reminder tone enabling contact exchange enabling exchange calendar enabling SAC when DND is active enabling SAC when DND is active enabling a week day for calendar reminder setting a week day for calendar reminder setting reminder time setting reminder time setting an agent on an observed call audio settings AGC button clicks AGC button clicks AGC button clicks 112 berror tones AGC button clicks 113 configuring hearing aid compatibility error tones 114 headset profile setting a primary ringtone setting headset mic level Autodialing calling a person 59 Callendar calendar reminder callendar reminder callendar reminder callendar reminder callendar reminder callendar calendar calendar calendar calendar calendar calendar calendar callendar exchange calendar reminder disable gerson 66 sexchange calendar reminder 102 exchange calendar 108 list style 110 month calendar event 100 reminder time 110 reminder tone 110 setting a week day for reminder 110 set		<u>V 1</u>		
disabling calendar reminder tone disabling contact exchange disabling exchange calendar enabling calendar reminder enabling calendar reminder enabling calendar reminder tone enabling contact exchange enabling contact exchange enabling exchange calendar enabling exchange calendar enabling exchange calendar enabling SAC when DND is active enabling a week day for calendar reminder setting a week day for calendar reminder setting reminder time setting reminder time setting snooze time Assisting an agent on an observed call audio settings AGC button clicks AGC button clicks configuring hearing aid compatibility error tones feature to the setting a primary ringtone		109	C	
disabling contact exchange disabling exchange calendar enabling calendar reminder enabling calendar reminder tone enabling contact exchange enabling contact exchange enabling contact exchange enabling contact exchange enabling exchange calendar enabling exchange calendar enabling SAC when DND is active enabling a week day for calendar reminder setting a week day for calendar reminder setting reminder time setting reminder time setting snooze time Assisting an agent on an observed call audio settings AGC button clicks AGC button clicks configuring hearing aid compatibility error tones headset profile setting a primary ringtone calling a person callendar reminder calling a person disabling calendar reminder disabling calendar reminder sexchange calendar exchange calendar reminder month calendar reminder exchange calendar reminder month calendar veent month calendar reminder month calendar veent sexchange calendar month calendar reminder under month calendar month calendar month calendar reminder under month calendar reminder under month calendar month calendar reminder under under month calendar month calendar reminder under under month calendar remind				
disabling exchange calendar 108				
enabling calendar reminder				
enabling calendar reminder tone				
enabling contact exchange				
enabling exchange calendar			disabling calendar reminder	<u>109</u>
enabling SAC when DND is active 111 setting a week day for calendar reminder 110 setting calendar list 110 setting reminder time 110 setting snooze time 110 setting an agent on an observed call audio settings AGC 112 button clicks 113 configuring hearing aid compatibility 115 error tones 114 headset profile setting a primary ringtone 117 setting headset mic level 115 Autodialing calling a person 159			exchange calendar	<u>108</u>
setting a week day for calendar reminder 110 setting calendar list 110 setting reminder time 110 setting snooze time 110 setting an agent on an observed call audio settings AGC 112 button clicks 213 configuring hearing aid compatibility error tones 114 headset profile setting a primary ringtone 2117 setting headset mic level 115 autional setting a person 159 month calendar event 50 mont			list style	<u>110</u>
setting calendar list			month calendar event	<u>66</u>
setting reminder time setting snooze time 110 reviewing event 660 setting a week day for reminder 110			reminder time	<u>110</u>
setting snooze time			reminder tone	<u>109</u>
Assisting an agent on an observed call 91 audio settings AGC 112 button clicks 113 configuring hearing aid compatibility 115 error tones 114 headset profile 116 setting a primary ringtone 117 setting headset mic level 115 Autodialing 219 Autodialing 291 setting a week day for reminder 110 snooze time 110 snooze time 50 URI dialing 20 call forward, disable 67 enable 211 call forwarding 211 call forwarding 211 call forward busy 211 call forward no answer 36 call forward no answer 36			reviewing event	<u>66</u>
audio settings snooze time 110 AGC 112 call button clicks 113 recents 50 configuring hearing aid compatibility 115 URI dialing 83 error tones 114 disable 67 setting a primary ringtone 117 enable 67 setting headset mic level 115 call forwarding call forward busy 66 Autodialing call forward no answer 66			setting a week day for reminder	<u>110</u>
AGC 112 call button clicks 113 recents 50 configuring hearing aid compatibility 115 URI dialing 83 error tones 114 disable 67 setting a primary ringtone 117 enable 67 setting headset mic level 115 call forwarding call forward busy 66 Autodialing call forward no answer 66		<u>91</u>	snooze time	<u>110</u>
button clicks		112	call	
configuring hearing aid compatibility 115 error tones 114 headset profile 116 setting a primary ringtone 117 setting headset mic level 115 Autodialing 219 calling a person 259 URI dialing 83 call forward, disable 67 enable 211 call forwarding 221 call forward busy 261 call forward no answer 662			recents	<u>50</u>
colligating hearing aid compatibility error tones			URI dialing	83
headset profile				
setting a primary ringtone			•	67
setting a primary fingtone				
Autodialing calling a person call forward busy	- · · · · · · · · · · · · · · · · · · ·			_
calling a person 59 call forward no answer	<u> </u>	<u>115</u>		66
Calling a person	•			
	calling a person	<u>59</u>		<u></u>

call history <i>(continued)</i>	configuring provision server	
viewing <u>5</u>	file server address	<u>20</u>
calling	connecting	
corporate database list3	<u>7</u> Wi-Fi	<u>124</u>
dial pad3		
emergency calling38, 3		123
local Contacts list3		
Main Menu3	-	
Calling a number	contacts	<u></u>
using Autodial <u>5</u>		/11
calling intercom group		
calling intercom		
Call observation		
	adding members to a Contacts group	
activating	_	
deactivating9		
calls	creating a new group	
beacon LED <u>10</u>		
consultative transfer7		
e.164 dialing <u>3</u>	8 details	<u>43</u>
editing a contact4	<u>3</u> editing	<u>42</u>
hold <u>4</u>	excluding contacts from your group	<u>46</u>
ignoring <u>3</u>	3 LDAP Directory	<u>48</u>
incoming call3	2 new contact	41
international3		42
multiple device access3		
muting a call4		
MWI10		
parking a call		
resume4		
speed dialing 3		
•		
switching phone	· · · · · · · · · · · · · · · · · · ·	<u>37</u> , <u>101</u>
unmuting a call		404
unparking a call		
visual alerting <u>102,</u> <u>10</u>		
call transfer	sharing	
blind <u>7</u>		
to a monitored phone9		
Call Transfer	coverage	<u>58</u>
Busy Indicator user <u>6</u>	3 crisis alert	
call transfer call transfer	acknowledge	<u>76</u>
attended <u>7</u>	<u>4</u> acknowledgement error	<u>77</u>
call transfer <u>7</u>	4 acknowledging again	<u>77</u>
unattended7	crisis alert watcher, emergency caller	75
collection		
delete13	1 -	
edit name	· IJ	
generating PDF	_	
sharing content	a a a a a a a a a a a a a a a a a a a	
conference, add participant using no hold conference 8	c E1100, initially incoming cano	<u>81</u>
conference, add participant using no noid conference <u>o</u>	deleting	
	a call record from the recents list	
adding a person on hold5	Torrioving a contact	<u>43</u>
details	- ucialis	
dropping a participant5	00114013	<u>43</u>
putting a call on hold5		
setting up <u>5</u>	3 Avaya SIP	<u>1</u> 28
configuring		
long term acoustic protection8	Open SIP	128

Index

dialing mode (continued)	extension (continued)	
automatic dialing99	blocking display	<u>60</u>
manual dialing <u>99</u>	unblocking display	<u>78</u>
Dial intercom call		
disabling bluetooth <u>112</u>	F	
display brightness	Г	
display settings	failover	126
changing the background image <u>117</u>	feature	120
date format	Hunt Group Busy	79
enabling screen saver clock <u>118</u>	features	<u></u>
language <u>119</u>	accessing features	56
setting backlight timer <u>120</u>	advanced	
setting screen saver time <u>118</u>	automatic callback	
setting text size121	blind transfer	
time format	call forward	
time zone	call parking	
documentation center	call pickup	
finding content	call pickup,	
navigation	call pickup directed	
documentation portal <u>131</u>	call pickup extended	
finding content	call recording	
navigation <u>131</u>	call transfer	
do not disturb	consultative transfer	
send all calls		
<u></u>	enabling Send all Call	
_	enhanced call forwarding68	
E	extending call to your cell phone	
F0500	interrupting a call with a whisper page	
EC500	multiple device access	
extend a call	parking a call	
forwarding call to your cell phone	priority call	
editing contact details43	unparking a call	<u>/ 1</u>
	Features Automotic collegels	ΕO
contacts	Automatic callback	
emergency calling	Bridged Call Appearance	
dial pad	Presence	
Emerg	Setting up Automatic Callback	
	finding content on documentation center	. 131
status screen		
emergency calls	G	
enable wireless headset		
enabling bluetooth	getting started	
enhanced call forwarding	connecting to Wi-Fi	
deleting a rule	login	<u>22</u>
editing a rule	groups,	
error tones	another group call pickup	
turn off	call pickup group	<u>71</u>
turn on		
Exchange authentication	Н	
basic	11	
OAuth	handset	
exchange contacts	AGC	. 112
Exchange credential	hearing aid compatibility	
Microsoft <u>106</u>	profile	
Microsoft®	headset	
excluding others from bridging	AGC	. 112
exclusion	mic level	
extension	11110 10 10 10 1	

headset (continued)	Main menu	<u>26</u>
profile setting <u>116</u>	making a call	
headset profile116	auto-dial	35
hold	dial mode	
putting a conference call on hold <u>54</u>	dial plan	8 7
Hunt Group Busy	Main menu	
using <u>79</u>	manual dial	
	precedence call	
	prefix digits	
I	priority	
	recents	
icons	using the dial mode	
MLPP icons30	malicious call tracing	
phone icons27	managing calendar	
presence icons		<u>0-</u>
identifying	messages visual alerting	103
device type		
ignoring	monitoring other extensions	<u>90</u>
incoming calls <u>33</u>	Multicast Paging	0.4
incoming call	overview	
audio alert <u>32</u>	sending a multicast page	<u>85</u>
decline <u>34</u>	multiple device access	
setting a ringtone	handling calls	
visual alert <u>32</u>	handling conference	
incoming call of a group member	limitations	
incoming calls	My Docs	<u>131</u>
do not disturb		
enabling call forward <u>67</u>	N	
send all calls111	IV.	
sending to coverage <u>58</u>	navigation	
information	navigating cluster	24
emergency caller <u>76</u>	selection	
Intercom group70	Navigation cluster	
microom group <u>ro</u>	left arrow, right arrow, up arrow, down arrow	2/
	network settings	
J	configuration	123
	mode	
Join a bridged call <u>61</u>	no hold conference	
I	no hold conference, add participant	<u>ot</u>
_		
LDAP Directory	0	
contacts48		
overview	optional components	<u>19</u>
Line keys	outgoing calls	
LNCC	blocking extension display	<u>60</u>
overview80	international	<u>38</u>
lock	unblocking extension display	<u>78</u>
unlock22	overview	<u>13</u>
log	call forwarding	6 6
calls50	Hunt Group Busy	
	•	
encryption	В	
logging out of your phone22	Р	
	phono	
M	phone	0.4
	boot-up	<u>21</u>
main menu	phone lock	401
language <u>119</u>	auto-lock	<u>108</u>

Index

phone lock (continued)		screen saver details (continued)	
manual lock	<u>22</u>	screen saver clock	<u>118</u>
unlock	<mark>23</mark>	screen saver time	<mark>118</mark>
phone settings		screen width	122
call history	106	searching	
call timers		corporate database	<mark>3</mark> 7
customizing phone keys		searching for content	
dialing mode		security	
key repeat delay	<u>50</u>	WEP, WPA/WPA2 PSK, 802.1x EAP	124
setting key auto repeat process	100	SENDALL	
log recent calls		Server	<u>oc</u>
setting mute alert		Avaya Aura	128
setting ridic diert		Open SIP	
visual alerting		service observe	
S .		setting network mode	<u>08</u>
physical layout	<u>10</u>	Ethernet	100
precedence call			
dial plan	0.7	Wi-Fi	<u>124</u>
making a call		settings	404
prefix digits		call history	
Main menu		call timers	
making a call	<u>86</u>	configuring calendar in your phone	<u>68</u>
Pre-configuration of keys		customizing keys	
overview	<u>87</u>	restoring keys to default	
Presence		date format	<u>120</u>
change your presence status	<u>88</u>	display settings	
change your presence status manually		brightness	<u>119</u>
DND invokes SAC	<u>111</u>	changing the screen saver	<u>118</u>
enabling contacts presence status	<u>88</u>	language	<u>119</u>
Presence integration		log recent calls	
viewing contacts presence		screen width	
presence status		time format	
away timer	105	time zone	
problems with the phone		visual alerting	
Product ID	<u>120</u>	shared control mode	
phone	127	sharing content	
protection	<u>121</u>	signaling	
long term acoustic exposure	81	SLA Mon [™]	
		sort documents by last updated	
provisioning server	<u>20</u>		<u>13</u>
		Speaker	444
R		AGC	112
		speed dialing	404
recents		contacts	
clearing all	<u>52</u>	removing contact	
clearing all entries	<u>52</u>	replacing contact	<u>101</u>
deleting a call record	<u>51</u>	stop	
making a call	50	alert view	
viewing call details	<mark>51</mark>	audio alert	
recording a call		visual alert	
recording audio parameters information		support	<u>133</u>
redial a number			
related documentation		т	
retrieving a voice message		Т	
Totalovang a voice message	<u>03</u>	team button	
_			O
S		speed dialing	
		viewing station status	
screen saver	<u>118</u>	Team Button	
screen saver details		transferring a call to a monitored phone	<u>95</u>

text input
enter, edit <u>25</u>
time zone
display settings <u>121</u>
settings
tracing calls96
U
unlockPIN
password
using
Hunt Group Busy <u>79</u>
V
videos
Viewing product ID127
product 1D <u>127</u>
W
watch list
Wi-Fi
••••
icons
accessing application98
overview <u>97</u>